

PITMAN'S MOTORISTS LIBRARY

The Book of the
MORRIS MINOR
AND THE
MORRIS EIGHT

JELLEY

PITMAN'S MOTORISTS LIBRARY

THE BOOK OF
THE MORRIS MINOR
AND THE
MORRIS EIGHT

A COMPLETE GUIDE FOR OWNERS AND
PROSPECTIVE PURCHASERS OF ALL MORRIS
MINORS AND MORRIS EIGHTS

BY
HAROLD JELLEY

FOURTH EDITION



LONDON
SIR ISAAC PITMAN & SONS, LTD.


1947

First Edition, July, 1935
 Second Edition, April, 1936
 Reprinted . . . May, 1936
 Third Edition, April, 1937
 Reprinted . . . July, 1938
 Reprinted . . . October, 1939
 Fourth Edition, June, 1940
 Reprinted . November, 1941
 Reprinted . . . June, 1947

SIR ISAAC PITMAN & SONS, LTD.
 PITMAN HOUSE, PARKER STREET, KINGSWAY, LONDON, W.C.2
 THE PITMAN PRESS, BATH
 PITMAN HOUSE, LITTLE COLLINS STREET, MELBOURNE
 UNITEERS BUILDING, RIVER VALLEY ROAD, SINGAPORE
 27 BECKETTS BUILDINGS, PRESIDENT STREET, JOHANNESBURG

ASSOCIATED COMPANIES
 PITMAN PUBLISHING CORPORATION
 2 WEST 45TH STREET, NEW YORK
 205 WEST MONROE STREET, CHICAGO

SIR ISAAC PITMAN & SONS (CANADA), LTD.
 (INCORPORATING THE COMMERCIAL TEXT BOOK COMPANY)
 PITMAN HOUSE, 381-383 CHURCH STREET, TORONTO



THE PAPER AND BINDING OF
 THIS BOOK CONFORM TO THE
 AUTHORIZED ECONOMY STANDARDS

MADE IN GREAT BRITAIN AT THE PITMAN PRESS, BATH
 D7—(T-5784)

INDEX

ACCIDENTS, what to do, 5
 Adjusting the brakes, 49
 — the tappets, 31

 BAD starting, 88
 Battery, care of, 91
 — charging switch, use of, 96
 —, topping up, 91
 Bishop's cam steering, 58
 Brakes, 49
 —, adjustment of, 49
 —, linings of, 51
 —, lubrication of, 51
 — shoes, 50
 Brushes, care of, 81

 CARBURETTOR, 37
 — adjustment, 42
 — faults, 39
 Care of the car, 16
 — of shock absorbers, 59
 — of tyres, 100
 Chromium plating, care of, 17
 Cleaning pistons, 27
 Clutch slip, 65
 Coil ignition system, care of, 84
 Commutator, care of, 81
 Comprehensive insurance policy,
 3
 Cycle of operations, 19
 Cylinder head, decarbonizing, 28

 DASHLAMP, replacing, 89
 Decarbonizing, 25
 Detection and remedy of ignition
 faults, 87
 Driving instruction, 14
 — licence, 1
 — off, 14
 Dunlop tyres, 100

 ELECTRIC horn, care of, 89
 Electrical equipment, 79
 Engine will not fire, what to do,
 87

FAULT finding tables, 97-99
 Field fuse, replacing, 82
 "Filling up," 13
 Fitting tyres, 103
 French chalk damage, 103
 Front wheels, care of, 59

 GREASING battery terminals, 91
 Grinding-in the valves, 28

 HEADLAMPS, care of, 89
 Hints on gear changing, 15
 How the engine works, 19
 Hydrometer, 93

 IGNITION system, care of, 84
 — warning lamp, 87
 Insurance, 3

 LICENCES, insurance, and law, 1
 Lighting system, care of, 89
 Lubrication, 68
 —, back axle, 72
 —, chassis, 77
 —, clutch, 72
 —, dynamo, 73
 —, gearbox, 71
 —, ignition distributor, 73
 —, steering gear, 73
 Lucas-Graves anti-dazzle system,
 91

 MAINTENANCE and overhaul, 25
 Misfiring, 88
 Motorist and the law, 5

 OILING carburettor piston, 40
 "Otto" cycle, 21
 Overhaul and maintenance, 25
 Overhead valve models, 105

 PETROLIFT, failure of, 44
 Pistons, cleaning, 27
 "Pitted" valves, 29
 Plugs, types of, 33
 Preparing for decarbonizing, 25


First Edition, July, 1935
Second Edition, April, 1936
Reprinted . . . May, 1936
Third Edition, April, 1937
Reprinted . . . July, 1938
Reprinted . . . October, 1939
Fourth Edition, June, 1940
Reprinted . November, 1941
Reprinted . . . June, 1947

SIR ISAAC PITMAN & SONS, LTD.
 PITMAN HOUSE, PARKER STREET, KINGSWAY, LONDON, W.C.2
 THE PITMAN PRESS, BATH
 PITMAN HOUSE, LITTLE COLLINS STREET, MELBOURNE
 UNITEERS BUILDING, RIVER VALLEY ROAD, SINGAPORE
 27 BECKETTS BUILDINGS, PRESIDENT STREET, JOHANNESBURG

ASSOCIATED COMPANIES

PITMAN PUBLISHING CORPORATION
 2 WEST 45TH STREET, NEW YORK
 205 WEST MONROE STREET, CHICAGO

SIR ISAAC PITMAN & SONS (CANADA), LTD.
 (INCORPORATING THE COMMERCIAL TEXT BOOK COMPANY)
 PITMAN HOUSE, 381-383 CHURCH STREET, TORONTO



THE PAPER AND BINDING OF
 THIS BOOK CONFORM TO THE
 AUTHORIZED ECONOMY STANDARDS

MADE IN GREAT BRITAIN AT THE PITMAN PRESS, BATH
 D7—(T.5784)

PREFACE

ALTHOUGH the Morris Minor has not been marketed for many years, there are still thousands in use to-day and it was for owners of this particular model that the first edition was introduced. The "Series" models replaced the Minor and maintenance points for these models also are dealt with in the present edition.

During 1937 I received a large number of requests for a chapter on the Overhead Valve Models, and this was included in the 1938 edition and it is left in in the present edition. I trust that it will be of assistance to those who still own one of the earlier Minors.

Every endeavour has been made to anticipate the requirements of the reader and, where I fail to fulfil these requirements, I shall be glad to hear from readers so that any useful information may be embodied in future editions of this book.

In conclusion, I should like to express my appreciation of the courtesy shown by Morris Motors Ltd. in supplying information and photographs which have assisted in the compilation of this book.

H. J.

LONDON

THE LEADING MOTOR INSURANCE COMPANY

GENERAL ACCIDENT FIRE AND LIFE ASSURANCE CORPORATION LIMITED

Life & Fire
estd. 1837



Casualty
estd. 1885

Chief Offices: GENERAL BLDGS • PERTH • SCOTLAND
GENERAL BUILDINGS • ALDWYCH • LONDON • W.C.2

The 'General' has long specialized in motor insurance, and, as a result, can claim to have insured more motor vehicles than any other company. Policies are issued at attractive terms for all classes of vehicles and carry a No-Claim Bonus rising to 25 per cent. The facilities of the 'General' provide unrivalled prompt service.

Assets £29,000,000

Claims paid £121,000,000

CONTENTS

CHAP.	PAGE
PREFACE	iii
I. LICENCES, INSURANCE, AND LAW	1
II. ON THE ROAD	8
III. HOW THE ENGINE WORKS	19
IV. OVERHAUL AND MAINTENANCE	25
V. LUBRICATION	68
VI. THE ELECTRICAL EQUIPMENT	79
VII. CARE OF TYRES	100
VIII. THE O.H.V. MODELS	105
INDEX	125

THE BOOK OF THE MORRIS MINOR AND THE MORRIS EIGHT

CHAPTER I

LICENCES, INSURANCE, AND LAW

THE first thing to do when you have purchased a new car is to prepare it and oneself for the road. There is the insurance policy and driving licence to be obtained, also the registration of the car. The latter is often carried out by the agent who sells you the car, but it is dealt with here in case you do it yourself.

All new applicants for a driving licence have to pass a driving test. This rule applies to any person obtaining a licence after 1st April, 1934. For those who wish to know all about the test I cannot do better than recommend them to Pitman's *Your Driving Test: How to Pass It*, 2s. net.

LICENCES

The Driving Licence. A declaration as to physical fitness must be made by every applicant for a driving licence. This declaration must be in the form prescribed by the authorities, and it must state whether or not the applicant is suffering from any disease or physical disability which would be likely to render it dangerous to drive.

The licence must be signed in the space provided before attempting to drive. This should be done immediately it is obtained.

A police officer may at any time stop a motorist, and ask to see his or her driving licence without giving any reason for so doing. If unable immediately to produce the licence, the driver cannot be convicted of an offence if, within five days of the request for production, he produces the licence *in person* at any police station he may specify.

When the court have ordered the licence to be endorsed, it must be produced in court *within five days* or such longer time

that the court may determine. If not the holder of a licence, but subsequently obtaining one, he shall produce it to the court within five days. Failure in either case entails automatic suspension of the licence until produced.

Renewing the Driving Licence. Upon the expiration of the licence at the end of twelve months, it will be necessary to complete a form for the application of renewal of driving licence and send this, together with the fee of 5s., to the appropriate local council offices from which the licence was originally obtained. Strictly speaking, one is then not allowed to drive owing to his not being in possession of a licence. It will usually be found, however, that if some proof is carried, such as a copy of any letter which may have been sent to the council, requesting the renewal of a licence, or the counterfoil of the postal order, if payment was made in this way, it will satisfy the police, should they wish to see the driver's licence. It is a good plan, however, to apply for renewal of the licence a week or so before the date the licence actually expires. Better still, the driver should call at the licensing authority's offices in person, when a renewal will be issued without delay.

Registration of the Car. Before the owner may take a car on the public highway it must be taxed, registered, and fitted with registration number plates, one at the front and one at the back.

The tax is worked on a horse-power basis at the rate of 25s. per horse-power, and in the case of a Minor or Eight is £10 per annum commencing on the 1st January and expiring on the 31st December. A quarterly tax is obtainable, the quarter days being 24th March, 30th June, 30th September, and 31st December. Alternatively, the car may be taxed from any day the owner wishes, the tax in this case to run to the end of the year.

Before a new car can be registered, the authorities will require some proof that the vehicle is brand new and demand production of the manufacturers' or agents' sales delivery note, or the agents' invoice, either of which should bear the engine and any other number by which the car can be proved not to have been previously registered. Also the authorities will require to see the certificate of insurance issued to the owner by the insurance company. These, and other details which the authorities will ask for, must be supplied on the appropriate form of application for a licence. In return for this form and the amount of the tax, the owner will receive a registration book and the licence. The latter must always be carried in the licence holder provided on the near side of the car. There is no necessity to carry the registration book, but the owner will be advised to read the instructions printed thereon. Upon the expiration of the licence

a renewal can be obtained either from the council with whom the vehicle is registered or from any post office authorized for this purpose. Fourteen days grace is allowed, but a post office cannot grant a renewal after the fourteen days grace has expired. This must be obtained from the authorities referred to above.

If the registration book is lost a new one can be obtained on payment of a fee of 5s. In the event of a duplicate being issued and the original subsequently found, return the original to the authority from whom it was obtained. If any alteration in the car, e.g. change of colour, or different type of body, which will affect the particulars previously registered, notify (in writing) the council of the alteration and forward the book for amendment.

If transferring ownership (1) deliver the book to the new owner; (2) notify the change, in writing, to the council whose name appears last in the book, also the index mark, and registration number, the make and class of the vehicle and the name and address of the new owner.

If the owner changes his address, enter particulars of new address in the space provided in the book and forward it to the council with which the car is registered.

INSURANCE

Before venturing on the public road with his car every motorist is now compelled to take out a third party insurance policy. In addition to the usual policy, or cover note, the insurance company will hand to the owner a certificate of insurance in the prescribed form, and, as already stated, when applying for his car licence, the applicant must—by production of the certificate or cover note—satisfy the licensing authority that the necessary cover against third party risks will be in force at the time the car licence becomes operative.

There is a very large number of insurance companies catering for motorists. Full information regarding rates¹ can be obtained on application to the companies, or from their agents, and an announcement of a well-known company will be seen in the front of this book.

A Comprehensive Policy. This type of policy is recommended (except when the car is an old one). There is some variation in the Private Car Comprehensive Policies issued by different companies; the following are brief particulars of the cover given by the office already referred to—

Third Party Risks. Unlimited indemnity in respect of claims by the public (including passengers not carried for hire or reward), or damage to property, against the policyholder or any person driving with his permission.

¹ Special rates are available for vehicles used for civil defence purposes.

The policy also covers the policyholder's liability whilst driving a private car or motor cycle not belonging to him and not hired to him under a hire-purchase agreement.

Liability for hospital expenses and emergency treatment under the Road Traffic Acts is included.

Loss of or Damage to the Insured Car and/or Accessories and Spare Parts from Any Cause. Exceptions include: loss of use, depreciation, wear and tear, mechanical or electrical breakdown, damage to tyres by application of brakes or by road punctures, cuts or bursts.

The insurance company bears the reasonable cost of removing the car from the scene of the accident to the nearest repairers, and the reasonable cost of delivery to the owner after repairs. Repairs, up to a reasonable amount, may be executed without prior notice to the company, provided that a detailed estimate is supplied forthwith.

Injuries to Occupants (caused by accident in direct connection with the insured car). Personal accident benefits in respect of policyholder and wife or husband: in case of death, £1,000; loss of two limbs or sight of both eyes or one limb and one eye, £500; loss of one limb or sight of one eye, £250. Medical expenses incurred by any occupant or driver not exceeding £20 per person for any one accident. Weekly payments during incapacity can be insured for a small additional premium.

Loss of Rugs, Coats, and Personal Luggage. From the insured car by fire or theft, up to £5 per article or £20 per year of insurance. Money, valuables, etc., are not covered, and this section applies only in Great Britain, N. Ireland, the Isle of Man, and Channel Islands.

Legal Defence. The company will pay the solicitor's fee for defence of any proceedings in any Court of Summary Jurisdiction, and representation at any coroner's inquest or fatal accident inquiry arising from any event which may be the subject of Third Party Indemnity under the policy.

Continental Touring. Provided prior notice in writing is given to the corporation of each proposed journey, the policy will be extended to apply for a total period not exceeding one-fourth of its current period while the insured car is temporarily in the Irish Free State, on the Continent of Europe, or in Algeria or Tunisia, and while in transit between ports in such countries, subject to certain restrictions.

No-claim Bonus. If no claim has been made or is pending, the renewal premium is reduced by 10 per cent first renewal, 15 per cent second renewal, 20 per cent third renewal, 25 per cent fourth and subsequent renewals.

THE LAW AND THE MOTORIST

Accidents. (What to do.) It cannot be too strongly emphasized that in an accident of any kind, it is most important for all those concerned to keep calm, and say as little as possible. The natural tendency is to become flurried and perhaps make some rash statement which may later be regretted.

The first thing to do, in the event of any person being injured, is to obtain medical assistance and a policeman. This may in some circumstances be rather difficult, should the accident occur in some out-of-the-way place, but it is usually possible to find a telephone within a mile or so from any spot in England at any rate.

Having done all that is possible in this connection, take the names and addresses of all available witnesses, particularly any disinterested parties. Get the policeman to take note of the positions of the damaged vehicles, and of any marks on the road which may be of assistance at a later date.

Do not omit to report the matter to your insurance company within twenty-four hours from the time of the accident; also advise your motoring associations. Should a policeman not be on the spot the accident *must* be reported at any police station, within twenty-four hours. Do not deal with any correspondence yourself. This should be posted to your insurance company, road association or solicitor, as the case may be. Never offer any money to an injured person or to a witness at any time, as this may be taken as admitting liability.

Address. If a motorist is accused of driving recklessly, dangerously or carelessly, he must give his name and address to any person having ground for requiring the information. If he refuses or gives a false name and address he is guilty of an offence.

Arrest. A police officer, whether in uniform or not, who observes the driver of a car commit the offence of reckless, dangerous or careless driving may arrest him without warrant unless he gives his name and address or produces his driving licence for examination.

It is not generally known that, under the Highways Act, 1835, a person who sees a motorist driving furiously to the danger of any person may arrest the motorist without a warrant.

Endorsement of Licence. On conviction of a motorist for a road offence an order is sometimes made for the nature of the offence to be endorsed on the licence. Details of endorsements are also sent to the authorities granting the licence, but, if the holder has a good driving record for three years from the date of the last endorsement, the offences are not recorded on any new licence

issued. It is not permissible for a police officer to take notes of any endorsement.

Driving Test. A driving test is provided for in the case of all new holders of driving licences, but this regulation does not apply to a person who held a driving licence before the 1st April, 1934. The form of the official test includes such matters as examination in the Highway Code; starting a car, overtaking and backing the car within a limited space. The full regulations are issued by the Minister of Transport. Licences issued before the test are marked "provisional," and the holders are liable to be called upon to pass the specified test during the period of the licence.

Speed Limit. Authority has also been given for the general speed limit in built up areas to be fixed at thirty miles an hour in daylight and 20 m.p.h. during black-out time. A "built up area" is defined as a length of road in which a system of street lighting is maintained by lamps not more than two hundred yards apart. It must be remembered, however, that in certain areas, such as the Royal and municipal parks, there are definite limits to the speed of road vehicles at all times.

Reckless, Dangerous, or Careless Driving. These forms of driving are regarded as very serious offences and may result in imprisonment and disqualification from holding a licence. Motorists must not drive on a road recklessly, or at a speed or in a manner which is dangerous to the public. Careless driving is defined as driving without due care and attention or without reasonable consideration for other persons using the road. A police officer has power to arrest for these offences without warrant, unless the driving licence is produced or the driver's name and address is given to him. Anyone driving furiously to the danger of the public may be arrested by any person without a warrant.

Driving Under the Influence of Drink or Drugs. If when driving, or attempting to drive, or in charge of a motor vehicle any person is under the influence of drink or a drug so as to render him incapable of having proper control of the vehicle, he is liable to heavy penalties of fine or imprisonment, or to both fine and imprisonment. Disqualification from holding a licence for twelve months may be imposed if the Court thinks fit.

Accident Procedure. If when on the road a motorist is concerned in an accident whereby damage or injury is caused to any person, vehicle, or animal (including any horse, cattle, ass, mule, sheep, pig, goat, or dog) the driver must stop and, if required so to do by any person having reasonable grounds for so requiring, give his name and address and also the identification marks of the car. If such details are not given at the time of the accident, the driver must within twenty-four hours report the accident at a police station or to a police officer.

When involved in an accident requiring medical assistance, the driver should do everything possible to render aid to those injured.

It is advisable to give to those concerned only essential details, and not to make any statement which may afterwards have a detrimental effect on your own position and also on that of the insurance company.

If possible, secure the names of likely witnesses of the accident so that your legal advisers and insurance company can take all steps necessary to protect your interests.

Motor Horn Silence. A motor horn should not be used at any time when a vehicle is stationary on the highway, but an exception is made when it is necessary to do so for reasons of safety.

An order is in force which provides that no person shall sound any instrument fitted to any motor vehicle for signalling its approach by sound between the hours of 11.30 p.m. and 7 a.m. on any road on which there is provided a system of street lighting, furnished by means of lamps placed not more than 200 yards apart.

Traffic Lights. The red, green and amber lights are now familiar to all road users. The red and green discs give definite "Stop" and "Go" instructions, and the chief difficulty has been the amber light. Simultaneous lighting of red and amber discs means "prepare to start," and the crossing should not be taken until the green light is displayed. Amber following the green light is equivalent to stop, unless the vehicle is in such a position as to render crossing essential—to prevent an accident through sudden stoppage, or to avoid obstruction. Do not attempt to "race the lights."

Pedestrian Crossings. Drivers approaching a crossing are to proceed at a speed that will enable them, if required, to stop before reaching the crossing. Where the crossing is not controlled by a police officer or light signals, pedestrians have precedence over all vehicular traffic at these crossings. Drivers are not to stop on any crossing unless it is necessary to do so to avoid accident. Keep a most careful look-out when driving during black-out periods.

Brakes. The police have power to test the brakes or steering, and this may be carried out in a garage *with the owner's consent*, but 48 hours' notice must be given to the owner. The notice does not apply in the case of a vehicle involved in an accident within the previous 48 hours.

Mascots. A mascot must not be fixed in a position likely to cause injury to any person in the case of a collision.

Windscreen Wiper. The screen must always be kept clear and the wiper(s) maintained in good working order.

CHAPTER II

ON THE ROAD

THIS chapter is *entirely* for the beginner and is in terms which can be easily understood.¹ Firstly, the controls and gear positions should be thoroughly examined, and here, Figs. 1, 2, 3, and 4 should be of some assistance. The best way in which to become familiar with the controls is to sit in the driving seat.

Probably the first thing you will notice is the gear lever. This is on your left and is the longer of the two levers, the shorter one being the handbrake. The handbrake is in operation when pulled back and will stay on until the ratchet catch lever is pressed. This is done by pulling the lever back and squeezing the hand, this action releasing the catch.

The next thing to catch your eye (or more truthfully, your foot) is the clutch pedal. This is the left pedal, and, with the exception of the brakes, is the most important control on the car. Its object is to break the drive between engine and gearbox. This is necessary, for example, when changing gear. Constant slipping of the clutch, however, should be avoided. Some people imagine the clutch should be slipped to enable the car to crawl up a hill, or go slowly through traffic in top gear. The gearbox is supplied for occasions such as these.

The pedal next to the clutch is the throttle or accelerator, and is the middle pedal. This pedal regulates the supply of petrol gas to the engine, and thereby the speed and power of the car. It works with immediate effect, and any sudden acceleration or deceleration of the engine has to be transmitted to the car in the form of extra or less speed, and is bound to cause a strain on the clutch and other parts of the car responsible for turning the back wheels. The next pedal is the foot brake. The function of this needs no explaining, but it may be well to state here that the brakes should be treated with respect. Fierce application, in wet weather will, in all probability, start a skid which the driver may find difficulty in correcting.

Going back to the gear lever and looking down, a round black knob will be seen behind the gear lever in the centre of the floorboards (on the dashboard on Series models). This is the starter button. Pressure on this knob has the result of turning the crankshaft of the engine, the same as is obtained by turning

¹ The text deals mainly with the Minor controls. See Fig. 3 for the positions of the Eight controls, and Fig. 4 for the Series "E" controls.




FIG. 1. THE CONTROLS OF THE MORRIS MINOR

the starting handle. This knob should be operated firmly and should be released immediately the engine fires.

On the left of the speedometer (below on some Series "E" models) will be found a projecting knob. This controls the strength of the mixture (and slow-running on the Series "E" models) that is fed by the carburettor to the engine. When starting from cold, this knob should be pulled out as far as it will go, but on no account should the engine be run for any length of time with the knob in this position. If this is done, neat petrol will be drawn




FIG. 2. THE GEAR POSITIONS OF THE THREE-SPEED GEARBOX

into the cylinders, which will break down the oil film and may cause considerable damage. When the engine is pulling evenly this knob should be pressed inwards as far as it will go without causing the engine to spit or splutter. If the engine fails to run evenly with the mixture control knob pushed right in, it is probable that the engine is not warm enough.

On the right of the speedometer will be found another projecting knob. This is the slow running control, which controls the speed of the engine when the foot is off the accelerator pedal. Turning it to the right decreases the engine speed, while turning to the left has the opposite effect. It should be set so that the engine is just ticking over and then left in this position.

On the right of the instrument board in front of the driver is a large black switch set in a circular dial. This controls the electrical circuits, serving the dual purpose of controlling the dynamo output and the lights. There are four positions for this switch. When in the position in which the pointer head coincides with the words "Summer Half," it indicates that the dynamo is

on half-charge and only giving half its normal output. When the pointer coincides with the words "Winter Full," the dynamo is delivering its full output. When the pointer coincides with the word "Side," it means that the side and tail lamps are alight. When pointing to "Head," this means, of course, that the head and tail lights are on. During the summer months the switch should be kept on the "Summer" mark, and during the winter on the "Winter" mark, as obviously the demand is then greater.




FIG. 3. THE CONTROLS OF THE EIGHT (1938)

KEY TO FIG. 3

- | | |
|---------------------------|----------------------------------|
| 1. Handbrake lever | 10. Ammeter |
| 2. Gear lever | 11. Slow-running control |
| 3. Starter button | 12. Lighting and charging switch |
| 4. Ignition warning light | 13. Trafficator control |
| 5. Petrol gauge | 14. Head light dipper |
| 6. Mixture control | 15. Horn button |
| 7. Oil gauge | 16. Clutch pedal |
| 8. Speedometer | 17. Throttle pedal |
| 9. Dash light | 18. Footbrake pedal |

(The switch on the Series "E" models has three positions, "Off," "Side," and "Head," and as the dynamo is of the compensated voltage type no charging switch is fitted.)

In the centre of the switch is a removable key. This serves to switch the ignition on and off. Turning the key clockwise switches on the ignition, turning it anti-clockwise switches off the ignition. *If you remove the key when parking your car, put it in a safe place.*

In the centre of the panel is a red indicator light. When the

dynamo output is insufficient to supply the needs of the ignition system the red light appears, indicating that current is being drawn for ignition purposes from the battery. *Never leave the engine idling or stationary for long periods with this red light showing.* If you do, it is quite likely that you will find your battery has been drained. Make a practice of switching the ignition off, when the stop is to be of some duration.

The advance and retard control lever is shown in Fig. 1. When the engine is running slowly, or when it is being started, the ignition should be retarded, i.e. the lever should be pulled back. When the engine is running fast, and also for normal running,




FIG. 4. THE CONTROLS OF THE SERIES "E" MODELS

the lever should be pushed right forward. This is the fully advanced position. Always keep it in this position, provided the engine is not showing signs of distress, i.e. spits, knocks, or backfires. (Series "E" models are fitted with fully automatic ignition control and no lever is therefore fitted.)

In the centre of the panel is the speedometer; this indicates the speed at which you are travelling and also the total mileage the car has run. This can be of great assistance when working out running costs.

To the right of the speedometer is a somewhat smaller instrument, which is the ammeter. Its sensitive finger swings both to the right and to the left showing that the battery is being charged or discharged. When the lights are off and the dynamo and ignition switch is turned to the "Winter" position, the ammeter needle should swing over to the right-hand side until it reads about 8 amps. when the car is running between 20 and 25 miles

per hour. If the ammeter does not register when the dynamo and ignition switch is on, and the car is travelling at this speed, it means either that the fuse has blown, or that attention is necessary to the electrical system (see Chapter VI).

To the left of the panel near the centre is the oil gauge which gives indication of the pressure of the oil being fed to the engine. The pressure should be about 50 lb. when the engine is warm and the car is travelling at about 30 m.p.h., or 60 lb. in the case of the Series "E."

The remaining instrument is the electric petrol gauge, which gives indication of the petrol tank contents. It should be noted that it only registers when the ignition is switched on.

Having mastered the controls we now prepare the car for the road.

Filling-up. First see that the radiator has sufficient water (rain water is preferable), then make sure that there is sufficient petrol in the tank. This can be verified by reading the gauge on the instrument panel (see Fig. 1). The tank capacity is five gallons (5½ gall. Series "E"). Now check the oil supply in the engine sump. This may be done by using the dipstick. Remove the "stick" with hooked end which will be found projecting on the right-hand side of the engine between the filler spout and the dash. Wipe the lower portion of the "stick," reinsert and withdraw. Oil will cling to the stick, thus showing the actual quantity present in the sump. The correct level is indicated by a deep depression on the "stick," and the engine should *not* be run for long periods when the oil has dropped below the half-full level. The filter should on no account be removed when replenishing with oil. Clean, fresh oil is essential for good running and freedom from breakdowns.

Starting-up. First see that the gear lever is in neutral (see Fig. 2). Then turn the key in the switch on the switchboard (see Fig. 1) and wait until the S.U. petrol pump ceases to pump. Pull the mixture control knob at the left of the instrument panel right out.

The engine-starting switch is controlled by the round black knob in the centre of the floorboard (on the dashboard in the case of the Series "E" models) next to the gear lever. When this switch is operated the engine will be heard revolving and should start firing, when the starter switch should be immediately released. In cold weather it is advisable to swing the starting handle with the ignition switch off before using the self-starter. It is bad practice to keep the starter switch depressed if the engine is not revolving as sometimes happens if the battery is run down, or with a new stiff engine, or in very cold weather. Use the starter sparingly, and it will repay you by giving good, trouble-free service.

Driving-off (three-speed model). Having got the engine turning over slowly, press the clutch pedal down (which is the left-hand pedal) and then engage low gear. Do not force the gear in; it should engage quite easily. Now release the handbrake and let the clutch pedal come up gradually; at the same time increase the speed of the engine by gentle pressure on the accelerator pedal. The car should now be moving smoothly away. The beginner will probably find that he either stops his engine or starts off with a jerk. This is caused by letting in the clutch too quickly and should be rectified at an early stage, as enormous strains are placed upon the transmission.

After having travelled some few yards the driver should try to change into second gear. (The road speed will be in the region of 10 m.p.h.) To do this, again press the clutch pedal down, bring the gear lever into the neutral position, release accelerator, then swing the lever to the right and push it forward, which will engage the second speed gear. The clutch pedal may now be released and the accelerator depressed simultaneously. Care must be exercised when making the change to avoid pushing the gear lever into the reverse position. If a light pressure to the right of the gear lever is maintained while making this change, no damage will be done.

Changing to top gear is perhaps the easiest of all. Simply press the clutch pedal down, release accelerator, pull the gear lever straight back, and you are in top and on again depressing the accelerator should be travelling at a respectable speed. Remember, however, that the engine is new, and don't exceed 30 m.p.h. until it is well run in, i.e. at least 500 miles. The great thing to remember is that you can always stop by pressing the clutch and brake pedals down hard. (Extreme left and right pedals respectively.)

When the engine is cold and the gearbox oil thick, the gear change should be made quickly, otherwise the gearbox will audibly protest.

Referring to Fig. 2 again, the reverse gear position will be seen to be top left. This gear is obtained in the same way as the other positions with the difference, of course, that the car is stationary. *Never* try to engage reverse while the car is in motion, as this sets up terrific strain on the gear wheels and might cause a serious breakdown.

Four-speed Model. The gear positions on this model are entirely different from those of the three-speed model just described. Therefore, we will commence from the beginning again for the benefit of the owner of the four-speed model.

Starting from neutral, with the engine turning over slowly, press the left pedal down (clutch) and then swing the gear lever

to the left and forward. Now release the handbrake. The pressure on the left pedal may now be lightened, at the same time gently pressing the accelerator pedal with your right foot, when you should glide slowly away. If the engine stops (as it probably will do until you are used to it) you must push the left pedal down and bring the gear lever back to neutral, start the engine and begin again.

You are now in low gear and should stay there until you feel safe enough, and the engine speed fast enough to change up to the next position. This change is made very easily. Simply put out the clutch, release the accelerator pedal, pull gear lever right back in a straight line, and you are then in second. Now take your foot off the clutch again and press the accelerator pedal.

To change into third gear, press the left pedal down, release accelerator, push gear lever forward with right hand pressure, through neutral, and then forward again. You may now take your foot off the clutch and press the accelerator pedal.

You are now travelling somewhere in the region of 25 m.p.h., and you will be well advised to stay there until you feel perfectly confident to make the next and last change, e.g. to top. This is done by pressing the left pedal down, releasing accelerator, bringing the gear lever straight back, releasing the clutch pedal and pressing the accelerator pedal again. You are now in top and doing famously, but don't take any liberties. All you have to do now is to watch your steering and use the accelerator pedal as the contour of the road demands. Remember to keep the left side on the road and to slow down when approaching cross-roads and corners.

The reverse position is backward on the extreme right. Care must be taken when changing from third speed into top to avoid pushing the gear lever beyond the neutral position into reverse. This is guarded against by a spring-loaded safety fence, the resistance of which must be overcome to move the lever into reverse position.

A Few Hints on Gear Changing. If you have bungled the gear change, and cannot get into the desired position, don't lose your temper and try to force the lever into position. Stop the car by pressing the clutch and brake pedals, get the lever back into the neutral position, and start again from the beginning. Not only will this save the gears from being damaged, it will also give you additional practice. Remember the old saying "Practice Makes Perfect," and you will realize you are not wasting time.

As already stated, you should never try to engage a "forward" speed while travelling backwards or *vice versa*; reverse while travelling forwards. Make certain the car is stationary before engaging a gear which will reverse the direction of travel.

When changing to a higher gear the left (clutch) pedal

must always be pushed down and the foot removed from the accelerator pedal until the change has been made. A slight pause in the neutral position may be advisable when the engine is hot.

When changing down to a lower gear, the clutch pedal should be depressed, and after waiting for approximately half a second with the right foot pressing on the accelerator pedal, so that the engine can gain speed, the change can be made.

Double de-clutching (practised by all "old hands") is the best method for changing down on those gearboxes which have not got synchromesh gears. (The beginner should not attempt this, however, but must wait until he has had a certain amount of "straight" gear changing.) The procedure is as follows—

Holding the gear lever lightly, push down the clutch pedal, move the gear lever into neutral position, and let the clutch pedal rise again. Now "rev" the engine up by pressing the accelerator pedal, put the clutch out and move the gear lever into the required position, once more releasing the clutch. After a time this will become "second nature," and all downward gear changes will be positive. A great point to remember is that you should never look down when changing gear.

CARE OF THE CAR

Running-in New Engines. After buying a brand new Morris, special caution must be exercised for a certain period of driving, in order to allow all moving parts to become bedded down and bearing surfaces to harden. Any attempt to expedite matters is doomed to failure and may permanently spoil the engine. Until 500 miles have been covered, a speed in excess of 30 m.p.h. in top gear should not be attained, and large throttle openings should not be used. The first 500 miles of an engine's existence are far more important than the next two thousand. When starting from cold allow the engine to turn over at a fairly fast speed.

New engines should be given frequent attention during the first 500 miles if they are to give long and trouble-free service. After the first 250 miles the tappet clearances should be checked and adjusted if necessary (see page 33). The cylinder head stud nuts should also have attention at the same time. The oil should be drained and the engine refilled with fresh oil after the first 500 miles have been covered; the oil filter should be thoroughly cleaned at the same time.

Care of the Wings. The wings are cellulosed and should not be rubbed with a dry duster, as this is likely to scratch the surface. Always rub them down with a soft sponge, using plenty of water. On no account attempt to remove tar spots with the aid of paraffin or a similar medium.

After the wings have been well washed down with hose and

sponge, all beads of water remaining should be carefully cleaned off with a chamois leather.

Chromium Plating. It should be noted that chromium plating does not require, and should not be treated, with metal polish, for it does not oxidize in the same manner as nickel-plating. The chromium-plated parts should be treated in the same way as the wings, and the surfaces will then improve with cleaning.




FIG. 4A. SHOWING THE JACK IN USE

Care of the Cooling System. The radiator should be kept almost full and, as stated previously, it is advisable to use only rain-water for this purpose, as ordinary tap-water contains lime, which will become deposited throughout the cooling system and possibly set up overheating owing to the radiator being affected. Any leaks at the hose connections should be corrected by tightening the clips, or, if necessary, re-making the joint. Naturally, only clean water should be used, and it is as well to filter the water through linen to make sure that no foreign matter can enter the radiator, which would clog up its tubes.

Winter Precautions. In extremely cold weather, care must be exercised so that water does not freeze whilst the car is in the garage. It is advisable to drain off the water when the car is put away. If this is not practicable (in the case of a doctor, for

instance), a radiator lamp may be used. These lamps are made on the principle of miners' lamps, and are absolutely fireproof. Special anti-freezing mixtures can be obtained, which, when emptied into the water, will be proof against freezing. Ordinary glycerine is also a good frost prevention, the necessary quantity being four pints of glycerine to each gallon of water, this being sufficient to stand against almost any degree of temperature which is to be experienced in this country. Any evaporation can be made good by simply adding rain-water.

Care of the Springs. The spring clips which secure the front and rear springs to the axles should be examined periodically to see that they are bolted up tight. It is essential, particularly when the car is new, to test the nuts on these clips to ensure that no slackness has taken place. The majority of spring failures are traceable to the fact that slackness has occurred at these points and has not been attended to.

CHAPTER III

HOW THE ENGINE WORKS

A CHAPTER of this kind is often thought relatively useless by the "expert," but I feel that the majority of our readers will, eventually, want to know exactly what work each part has to do. The power unit looks, but is *not*, complicated, and the illustrations (Figs. 5 to 8) will help to clarify matters.

The Engine. Referring to Fig. 5, all component parts are clearly shown, and the key provides an easy means of reference. The cylinder is of uniform diameter and, when the detachable head is in position, is closed at one end, the interior being machined to a glass-like smoothness. The piston is also uniform in diameter, and also closed at one end, and this is made to fit the cylinder as closely as possible, but still allowing it to move easily therein. The combustion chamber is the space between the top of the piston and the cylinder head, and it is essential for this to be gas-tight, so that the explosive mixture may be compressed without loss. It is impossible to make the pistons themselves a gas-tight fit within the cylinder, for, if this was so, the friction set up would render movement difficult and, very soon, impossible; hence, the piston is fitted with what are known as piston rings. These are rings of springy iron, and are inserted into grooves in the outer wall of the piston. Owing to their natural expansion, they press closely against the cylinder wall; therefore, no gas can get past them. When the engine is working, the piston moves up and down in the cylinder, but before the power developed can be utilized for propelling the motor-car, it is necessary to convert this movement into a rotary one. A main- or crankshaft is fitted in the crankcase, this being constructed with the necessary number of crankpins, one for each cylinder. The formation of a four-cylinder crankshaft may be seen from Fig. 6. The piston is connected to the crankpin by means of a connecting rod, which is fitted with suitable bearings at each end, so that as the piston works up and down the motion rotates the crankshaft. On the crankshaft is mounted a flywheel, the object of which is to store up the energy developed by the engine, so that the rotary movement of the crankshaft may be continued steadily and jerks obviated.

The explosive mixture, a mixture of fuel vapour and air, is induced to enter the combustion chamber through an inlet valve, while the exits of the products of combustion—carbon dioxide




FIG. 5. THE MINOR ENGINE

SP = Sparking plugs
 CC = Combustion chamber
 IV = Inlet valve
 EV = Exhaust valve
 VG = Valve guide
 VS = Valve spring
 T = Tappet
 F = Flywheel
 MB = Main bearing
 CS = Crankshaft
 OF = Oil filter
 S = Sump
 OP = Oil pipe
 OPD = Oil pump drive
 P = Piston
 GP = Gudgeon pin
 WS = Water space
 CD = Camshaft drive
 C = Camshaft
 CR = Connecting rod
 FP = Fan pulley
 DD = Distributor drive

and water vapour—are expelled through the exhaust valve. The valves are opened and closed by means of tappets, these being actuated by a camshaft which carries the necessary number of cams or protrusions (Fig. 7). As the cam comes into action the tappet is forced upwards, which action raises the valve. The valve closes after the cam comes out of action by means of a strong spring which encircles the valve stem.

The "Otto" Cycle. The majority of engines are operated on what is termed the "Otto" principle, a principle which is adopted




FIG. 6. THE STURDY AND WELL-BALANCED MINOR CRANKSHAFT




FIG. 7. THE CAMSHAFT EMPLOYED ON THE MINOR IS OF GENEROUS DIMENSIONS AND CARRIED ON BALL AND ROLLER BEARINGS

for the Minor and the Series "E" models. This type of engine is more generally known as the four-stroke, in that an explosion occurs in the cylinder only once for every four movements of the piston, i.e. two up and two down. This means that each valve, the inlet and the exhaust valve, must open only once for every second revolution of the crankshaft; hence, they are timed so that the camshaft revolves at half-engine speed. Generally, it may be said that the inlet valve is timed to open when the piston is at the top of its stroke, that is nearest to the cylinder head, and closes when the piston is at the bottom of its stroke, while the exhaust valve opens when the piston is at the bottom of its stroke and closes when it reaches the top. The explosive mixture is ignited by means of an electric spark. The electric current which causes the spark at the plug points is supplied by the battery and

induction coil. The spark is timed to occur once for every second revolution of the crankshaft, in the same way as the valves, and this takes place when the piston is at the top of its stroke and the combustion chamber is filled with compressed mixture.

When the explosive mixture is fired, a considerable amount of heat is generated, and the cylinder, piston and valves become very hot. This surplus heat, which cannot be converted into power, must be dissipated; hence, the cylinders are surrounded by water-jackets.

The Cycle of Operations. To describe the cycle of operations, it is advisable to begin at that stage when the piston is at the top of its stroke, both valves being closed, and here Fig. 8 will be of assistance. As the piston begins to descend on its first stroke the inlet valve is opened, and the suction caused by the descending piston in the gas-tight combustion chamber draws in a charge of explosive mixture from the carburettor. When the piston reaches the bottom of its travel, the combustion chamber is filled with mixture, and the inlet valve then closes. The piston next rises on its second stroke, and the mixture contained in the combustion chamber is compressed until by the time the piston has arrived at the top of the stroke—the compression stroke—a pressure of between 70 lb. and 80 lb. per square inch is obtained. At this moment a spark is caused to jump across the electrodes of the sparking plug, which ignites the mixture. As the mixture burns—it does not explode suddenly—the heat generated causes the gases to expand, and, therefore, the piston is forced down the cylinder on its third, or firing, stroke. When the bottom of the stroke is reached the combustion chamber is filled with inert gases, which must be expelled before a new charge can be induced into the cylinder. As soon as the bottom of the firing stroke is reached, therefore, the exhaust valve is timed to open, so that as the piston ascends on its fourth stroke these products of combustion are forced out into the exhaust pipe, and finally to the atmosphere. At the termination of this stroke—the exhaust stroke—the exhaust valve closes and the inlet valve opens, so that a new charge of explosive mixture may be taken in by the engine.

The four strokes of the engine are, therefore—

Induction, piston descending and inlet valve opened.

Compression, piston ascending, both valves closed.

Firing, piston descending, both valves closed.

Exhaust, piston ascending, exhaust valve opened.

Only the third stroke of the cycle is a power, or impulse, stroke; the other three strokes are carried out by the power stored up in the flywheel.

Multi-cylinder Engines. No cars are fitted with single-cylinder engines to-day, although such machines were common in the early days of motoring. In the case of multi-cylindered engines,




FIG. 8. THE PRINCIPLE OF THE FOUR-STROKE ENGINE

the cycle of operations in each cylinder is exactly the same as that described in the foregoing paragraphs, but the firing strokes are timed to occur one after the other, so that in a four-cylinder engine there is a power of impulse stroke for every half-revolution

of the crankshaft. The crankshaft of a four-cylinder engine is constructed with four "throws," these being in pairs, so that No. 1 (the cylinder nearest the radiator) and No. 4 are in the same plane, while Nos. 2 and 3 are placed at an angle of 180 degrees to No. 1 and No. 4.

With this arrangement of throws, it is possible to make the cylinders fire in two different orders, i.e. 1, 2, 4, and 3, or 1, 3, 4, and 2. The latter is adopted on Minor and Series engines.

CHAPTER IV

OVERHAUL AND MAINTENANCE

IN this chapter the author has aimed at putting in a convenient form all the information and data necessary to enable the Morris owner to keep his car and engine in first-class trim, and this it is hoped will be of value both to the beginner and expert. All motor-cars, and for that matter all mechanical contrivances, require periodic lubrication, minor adjustments, and occasional overhauling; and at regular intervals the I.C. engine requires to be decarbonized and the valves ground-in if a reasonable degree of efficiency is to be maintained. Lubrication is dealt with in Chapter V, therefore no further reference is necessary here.

DECARBONIZING, VALVE GRINDING, ETC.

Decarbonizing and grinding-in the valves of the Morris engine should be undertaken at every 10,000 miles. I give this figure on the presumption that the oil level during this mileage has been strictly in accordance with the maker's instructions. Many owner-drivers make the mistake of giving the engine "just a little extra"; this practice generally results in excessive oiling of the cylinder walls, and the oil works upwards on to the piston head, where it is burned by the exploding charge of petrol gas and formed into carbon. The presence of excessive carbon in the cylinder head can always be detected by the falling-off of power and "pinking," i.e. a metallic noise when the engine is pulling hard. When this is noticed, decarbonizing should be undertaken. "Pinking" is a definite complaint from the engine that it is dirty, and the job should be undertaken as soon as possible, after the noise has been noticed.

It is the best plan, when decarbonizing, to have ready all the necessary tools and materials. In addition to the standard tool kit, we shall need plenty of clean rags, paraffin, valve grinding paste, some jointing compound, and a deep flat tin for a washing bath. It is also useful to have one or two small wooden boxes to keep small parts, nuts, washers, etc., as these are liable to be lost if they are just laid on the garage bench. Having collected the required equipment we can now proceed. The first thing to do is to start the engine and leave it running until it is fairly warm. This has the effect of making any joints that have to be parted much easier, also it is more comfortable to work on a warm engine. Next, we move the car to a convenient spot where the

water from the radiator can be drained off. When this is done the car can be manoeuvred to the place chosen for the work. *Do not attempt to run the engine after the water has been run off.* Serious damage will be done if you do. Next remove the bonnet by unscrewing the two bolts which attach the bracket at the rear end of the bonnet rod to the scuttle rim. In the case of the Eight the best method is to disconnect the radiator support rods and tilt the radiator slightly forward till the bonnet hinge rod is clear of its support in the radiator. It will not be found necessary to remove the electric horn which is suspended on the radiator stay, as this can be swung round above the radiator stay and will not interfere with later operations. (On the Minor the horn is mounted on the cylinder head and must be removed.) Next, the tension of the fan belt should be released by slacking the dynamo clamping bolts, and the top water connection should be released from the cylinder-head block by removing the two attachment bolts. Care should be taken not to lose the joint washer, which should be placed in one of the wooden boxes which we have ready for loose parts of this description. We next remove the dynamo clamping bolts which we have previously slackened; this will allow the dynamo to be taken away (after all wires have been disconnected) and put into one of the boxes for safety. It will not be found necessary to remove the dynamo bracket from the cylinder head.

Next remove the high tension wires from the sparking plugs, taking care to replace the terminals after removing the wire. In the case of the Eight it is necessary to withdraw the distributor from the cylinder head by unscrewing the nut fastening the timing quadrant to the head. Do not disturb the pinch bolt attaching the distributor quadrant to the distributor. Now proceed with the removal of the cylinder head. This is held on to the cylinder block by nuts screwed to studs which pass through the cylinder head. These nuts should be slackened off in rotation, about half a turn at a time. This is important, as the complete removal of any one of these nuts before the remainder imposes uneven stress on the cylinder head and causes distortion. Having removed all the nuts we are now ready to lift the cylinder head from the block. The joint between the two must be broken, and this is best done by tapping the sides of the head with a wooden mallet, or if a mallet is not available, with a hammer, interposing a piece of wood to take the blow. It is possible that this may not be sufficient to break the joint, in which case it is permissible to insert a screwdriver or similar blunt wedge between the joint at the two places where the cylinder-head gasket has been cut away for this purpose. These will be found one either side of the engine. Care should be taken not to insert the screwdriver too far, or

damage to the gasket will result. Having broken the joint the head should be lifted clear of the studs, and little difficulty will be experienced if you are careful to lift the head squarely. Now lift the gasket off the cylinder head. This should be done very carefully, and force must not be used. Should it catch on the studs, or should the gasket be bent or otherwise damaged, it will be rendered useless, and a new gasket will be necessary before the cylinder head can be replaced.

Everything is now ready for decarbonizing the piston crowns, valve heads, and the face of the cylinder block. Turn the engine




FIG. 9. REMOVING CARBON FROM PISTON CROWNS

by the starting handle until two of the pistons are at the top of their travel. We then find that the remaining two pistons are at the bottom of their travel. In order that carbon may not get into these two cylinders the tops should be stuffed with rag. Now take an old screwdriver and scrape the carbon from the top of the piston and cylinder block. When this has been done, clean all trace of carbon with a rag which has been damped in paraffin.

When these two have been cleaned, bring the other two pistons to the top of their travel and repeat the process. Do not under any circumstances use emery cloth or other abrasive to give a final polish, as this can be very harmful. Do not forget to go round each valve and remove every trace of carbon. This can best be done with a small screwdriver (Fig. 9).

The removal of carbon from the cylinder head is the next job. Remove the sparking plugs and turn the head upside down on the bench and, again using the blunt screwdriver, scrape away all carbon deposit adhering to the surface of the combustion heads. When this is completed, carefully clean the head with a rag damped with paraffin.

Now turn your attention to the valves.

First remove the exhaust-inlet manifold by unscrewing the




FIG. 10. THE MORRIS VALVE COMPRESSING TOOL IN ACTION
(From "The Autocar")

three nuts. Now remove the cover plate on the near side of the engine, and be careful not to damage the composition gasket.

In order to remove the valves, the springs must be compressed, and by far the best way to do this is to use a valve spring compressing tool (Fig. 10), which may be obtained from any Morris dealer. When the valve spring is compressed we find two conical cotters at the end of the valve stem, and the removal of these will release the valve spring cap from the valve stem. The valve can now be withdrawn from the guide. This process can be repeated on the remaining valves, and if all the valves are removed, make sure that you know from which port they came; this is an important point. Should the valves become mixed,

however, it is perfectly easy to replace them in the correct order, as all the valves are clearly numbered on the head and the corresponding number will be found on the upper face of the cylinder block by the valve ports. Remove all traces of carbon from the valves and all will be ready to start the grinding-in process. It is my aim that this should be done easily and well, and the following process reveals the secret of good valve grinding. First of all obtain a coil spring that can be inserted in the valve




FIG. 11. SHOWING USE OF SPRING TO FACILITATE VALVE GRINDING

port, beneath the valve head (Fig. 11); this should not be too strong. Next take the valve to be ground and coat the bevelled surface with valve-grinding paste, insert the valve in the guide with the spring just mentioned behind the head, and with a screwdriver (a suction type of tool (see Fig. 12) is required for the Series valves) oscillate the valve on the seating, and here is the secret of good valve grinding. Every few oscillations allow the spring to raise the valve from the seating, then give the valve half a turn and continue. Always give that half-turn to a fresh position every few oscillations, the object of this being that constant grinding with the valve in one position will cause circular grooves to be cut in the surface of the valve and its seating, which would prevent obtaining an absolutely gas-tight fit. Grinding should be continued until an even matt-like surface has been obtained on both the valve and its seating. Should the valve show a series of black spots on its face, it is what is known as "pitted," and if normal grinding does not remove these, the remedy is to have

the valve face trued up at a garage. Do not attempt to grind these pits out—it will only cause extensive damage to the seatings in the cylinder block; this is important, as it cannot be renewed. Should any valves show signs of distortion, they should be replaced by new ones, as any attempt at grinding will also cause damage to the seatings. When the valves have been ground-in they should be withdrawn and thoroughly washed in the paraffin bath, and the seatings and the valve ports thoroughly




FIG. 12. SHOWING THE SUCTION TYPE OF VALVE GRINDING TOOL IN OPERATION

cleaned with a rag moistened with paraffin. Do not attempt to wash away the grinding paste with paraffin owing to the danger of the paste finding its way into the valve guides or other working parts of the engine, where very serious damage would be done. Having satisfied yourself that all traces of grinding paste have been removed, the reassembling of the valves may be begun. This is a perfectly easy operation if you possess the compressing tool previously described, and should be carried out in the following manner.

Insert the valve in its guide, making sure that the valve is in the correct guide for that particular port, place the valve spring in position and then the valve spring cap. Now, with

the special tool, compress the spring until nearly the whole of the groove in the end of the valve stem is exposed. Now insert the two conical cotters in the groove, small end upwards, and release the spring. Having released the spring make sure that the cotters are properly engaged in the grooves.

It will be realized that the process of grinding will have removed a certain amount of metal from the valve head and the seating, so that it will be necessary to readjust the clearance between the valve stem and the head of the tappet. The amount of clearance recommended by the makers is .019 in.¹ (Fig. 13). This clearance can easily be checked by using the feeler gauge, which is attached to one of the special tappet spanners supplied in the tool kit. Many people use an ordinary visiting card for this process, but I strongly deprecate this practice, as visiting cards vary in thickness. Should the clearance be found incorrect, proceed as follows: at the upper end of the tappet will be found two flats, and with a spanner engaged on these hold the tappet against rotation (Fig. 15). Now slacken the steel nut with a $\frac{1}{4}$ -in. spanner, and without removing the spanner insert the feeler gauge between the tappet and valve stem. If you find the gauge cannot be inserted, rotate the tappet adjusting nut until the gauge can be inserted and withdrawn easily. When this has been done tighten the lock nut. It is always well to use the feeler gauge after the lock nut has been tightened in order to make sure that no movement of the setting took place while the lock nut was being tightened (Fig. 16).

It must, of course, be understood that the valve should be in the closed position when the adjustment of the tappets is taking place. In order that we may be sure that the tappet we wish to adjust is in the closed position, it is necessary to adjust them in the following sequence—




FIG. 13. SHOWING THE CORRECT TAPPET CLEARANCE

¹ S.V. engines up to No. 20712, .004 in. clearance; Nos. 20713 to 31750, .019 in. to .023 in. clearance; Nos. 31751 and onwards (4-speed models), .004 in. clearance. Series I, .019 in. Series II, .019 in. warm, .020 in. cold. Series "E" .017 in. warm, .018 in. cold.

Set No. 1 tappet with No. 8 fully open.

"	"	3	"	"	6	"	"
"	"	5	"	"	4	"	"
"	"	2	"	"	7	"	"
"	"	8	"	"	1	"	"
"	"	6	"	"	3	"	"
"	"	4	"	"	5	"	"
"	"	7	"	"	2	"	"

We now come to the replacement of the cylinder head, and it is here that cleanliness should be strictly adhered to. First




FIG. 14

To get at the valves on the Series "E" models the nearside front wheel must be jacked up and removed. The inspection panel should then be removed as shown above.

let us prepare the gasket for replacement. Remove any carbon adhering to the edges and coat both sides with an even film of jointing compound, and when this has been done place the gasket into position on the upper face of the cylinder block. In doing this I must stress the importance of keeping the gasket parallel with the cylinder head when it is being lowered over the studs. Do not use force should it bind on the studs. A short piece of tube, such as a box spanner, will be found very useful to push the gasket into position. Should the gasket be damaged, do not attempt to use it, but obtain a new one from a Morris agent. If required, Morris Motors Ltd. will supply other names.

The next operation is the replacement of the cylinder head.

Having made sure that this is quite clean, it can be lowered on to the cylinder block, once again keeping it parallel in order to obviate jamming on the studs. In the case of the Series 1 Models, insert the special cylinder head locating tool right home into the distributor spindle tunnel and replace the horn and dynamo brackets. When the cylinder head is in position replace the sixteen (thirteen on the Eight) cylinder-head nuts and tighten them up in the rotation indicated in Figs. 17 and 18. It will be




FIG. 15. TIGHTENING UP THE TAPPETS AFTER ADJUSTMENT

found best to tighten these nuts a quarter turn at a time until they are all up tight. Be sure only to tighten the nuts in the order indicated.

Our next job is the replacement of the sparking plugs, but before we do this let us make sure that these are in good condition. The following plugs are recommended for use in the Minor: Lodge C3, A.C. Sphinx type 331, K.L.G. K2, or, on the Eight, Champion 14 m/m. No. L.10 and Lodge C.14. Some of these plugs have the advantage that they can be taken apart for cleaning purposes by using two spanners, as shown in Fig. 19. When the plug has been taken apart, remove all traces of carbon and wash the interior of the steel body with paraffin. Next wash all the components in a petrol bath and dry them with a clean cloth.




FIG. 16. TESTING THE VALVE CLEARANCE





FIG. 17. SHOWING THE SEQUENCE IN WHICH THE CYLINDER HEAD STUD NUTS SHOULD BE TIGHTENED

Reassemble the plug and test the gap between the electrode and the points. The correct gap should be from .022 to .025 in. (.018 to .022 in. on Series "E" models).

Having completed this, replace the plugs and connect the high-tension leads, making sure to have the correct lead to each plug. We now replace the dynamo belt and dynamo. This involves the tightening of the dynamo cradle bolts (Fig. 20). It will, of course, be understood that the dynamo belt tension will be adjusted with this operation. When the distributor is replaced, the distributor rotating arm should be carefully rotated until the tongue of the lower end of the spindle engages with the slot on the upper end of the drive shaft. The tongue and slot are offset

FIG. 18. CYLINDER HEAD OF SERIES "E" MODELS
(Numbers denote sequence of nuts.)

to ensure their correct replacement. Set the distributor timing arm to the correct mark and tighten up the locking screw. We next replace the top water joint, not forgetting the joint washer, which we have safely in the box. Should this have been damaged, replace with a new washer. Using a damaged washer would result in a water leak, which is very undesirable. And now, having made sure that everything is in order, fill up the radiator with water, and while we are on the subject let us remind you that rain-water, or water which has been softened, is the most desirable for the radiator, as it obviates the possibility of clogging the circulating system with fur, which would lead to the overheating of the engine due to faulty water circulation.

Having filled the radiator, turn on the petrol, start the engine, and let it idle until it is thoroughly warm. Now switch off and again go over each cylinder-head nut, giving a final tightening up. It will be found that quite half a turn can be




FIG. 19. TAKING A PLUG TO PIECES FOR CLEANING PURPOSES




FIG. 20. ADJUSTING FAN-BELT TENSION

given to each nut. Be sure to adhere to the sequence given previously. And now a word of warning. *Do not attempt to speed up the engine until the final tightening of the head-nuts has been effected.* All that remains is to replace the cover from the valve chamber, swing the electric horn back to its original position and replace the bonnet.

When you have covered 250 miles after decarbonizing, the cylinder-head nuts should again be tightened up, and the valve cover removed and tappet clearance checked.

THE CARBURETTOR

The Minor and Series models are fitted with an S.U. carburettor, and I will endeavour to explain in the following pages the functions of this fitment. It will be clearly understood that the petrol which we have in the petrol tank must be atomized and mixed with air in the correct proportions, in order that easy combustion can take place, and it is the carburettor which does this. As the conditions of engine speed and load carried necessitate varying adjustment of the mixture proportions, it will be realized that in order to avoid complications this must be done automatically. The S.U. carburettor does this in the following manner. Reference to Fig. 21 will make this easier to follow.

Petrol flows into the float chamber through the union at the top. As the petrol rises in this chamber it causes the float to rise also. The float rises against a pivoted lever which engages with the lower end of a needle. The upper end of this needle terminates in a cone which engages in a corresponding conical orifice in the petrol feed and upon which it is forced by the lever. Thus the petrol supply is shut off when a predetermined level is reached. The lever and needle mechanism is attached to the float chamber lid, and can be readily detached by unscrewing the retaining nut in the centre of the float chamber lid.

The petrol is then fed to the jet, whose function it is to break up the petrol into a petrol mist. This mist is too rich in itself for the purposes of combustion, so air is drawn in through the air intake and automatically mixed with the petrol in the correct proportions. It is very easy to understand that the greater the demand on the engine, the more petrol air mixture will be needed. This is done on the S.U. carburettor by a tapered needle attached to the lower end of a piston. This piston is controlled by the suction from the engine. As the suction increases the needle is gradually withdrawn from the jet into which it slides. Thus the opening in the jet is enlarged, and more petrol is allowed to pass. The lower end of the suction-operated piston also works as a variable choke, which regulates the size of the passage in the

region of the jet as it rises and falls, thus maintaining an almost constant suction on the jet even though the engine demand varies.

The jet is so mounted that it may easily be moved up or down relative to the tapered needle, in order to weaken or strengthen the mixture over the working range.




FIG. 21. THE S.U. CARBURETTOR IN SECTION, CLEARLY SHOWING ITS INTERNAL CONSTRUCTION

This movement is regulated by a plunger situated on the instrument panel. The function of this control is to give a rich mixture, so that starting the engine from cold is an easy matter. It also ensures the even running of the engine when cold. The minimum jet opening can be set by means of an adjusting nut (clearly shown in Fig. 22), which forms the abutment for the enlarged head of the jet. This should be set as indicated on page 44.

As the S.U. carburettor is extremely simple, it is very unlikely that trouble will be experienced with any of the working parts.

The only adjustment which can be made, other than the slow running adjustment, is the fitting of a different size needle. This should not be undertaken, however, as the needle fitted at the works is of the correct size. It will be found that the suction chamber is sealed by the makers, which constitutes a broad hint not to interfere.




FIG. 22. AN ENLARGED SECTION OF THE JET ASSEMBLY

Let us now deal with the few troubles which may cause a stoppage on the road. These are very easily dealt with and may easily be avoided if the owner will spend a few minutes occasionally with an oil can. Let us deal with one cause, the piston sticking. Reference to Fig. 21 will show that the suction piston consists of the piston proper which forms the choke, the suction disk into which is inserted the hardened and ground piston rod which works in a bearing in the suction chamber, and the tapered needle which regulates the jet opening. This piston should operate freely, and it may save delay on the road if you make sure at regular intervals that this is so. This can be ascertained in the following manner: Insert the finger in the air intake and raise the piston, which, when the finger is released should return to its seat with a click. If it does not do this, the piston rod

is dry or sticky. To cure this, remove the oil cap nut on top of the suction chamber and pour in a few drops of good quality thin oil and replace the cap. Wakefield "Oilit" is particularly suitable for this purpose (Fig. 23).

Do not under any circumstances use a heavy oil such as engine oil for this purpose. Neither must oil be introduced to any other part of the suction chamber. Should it be found that oil is insufficient to free the piston a small quantity of paraffin can be




FIG. 23. FREEING STUCK PISTON

introduced in the oil cap and the piston worked up and down by means of the finger in the air intake. Should neither of these means free the piston you would be well advised to call in the aid of a Morris dealer, as it will be found that the piston chamber is sealed and should not be interfered with.

Another cause of irregular running of the engine is the presence of dirt or water in the petrol filter or in the float chamber, and you would be well advised to give a little time at intervals (say once a month) to cleaning these.

Let us deal firstly with the filter. This is to be found by unscrewing the large hexagon nut at the junction of the petrol pipe and the float chamber cover. Remove the filter, and with a stiff brush and some clean petrol thoroughly clean the gauze.

Do not use rag for this job as there is danger that fluff from the

rag will cause greater stoppage than the dirt which has been removed. When replacing the filter care should be taken to replace the coil spring first into the filter housing and see that you replace the filter with the open-end bearing on the hexagon nut.

It sometimes happens that water finds its way into the float




FIG. 24. TESTING FOR DIRTY JET

chamber, and an occasional inspection of the float chamber will be found well worth while.

Should you find that flooding is taking place, i.e. petrol constantly dripping from the air inlet, this may be caused by a particle of dirt on the seating of the float chamber needle. This is not very probable, as the incoming petrol tends to wash the seating clear of any particles of grit. But in order to make sure that this is not the trouble, remove the float chamber lid and twist the needle on its seating a few times. When flooding occurs always clean the filter housing.

Another cause of flooding which, fortunately, is extremely rare, is a punctured float. Should this occur I advise you to seek the aid of a Morris dealer for the repair or for a new float.

If dirt in the jet is suspected, this can be confirmed in the

following manner: With a small article—a pencil will do—raise the piston so that the jet can be seen through the air intake, and flood the carburettor by depressing the plunger on the float chamber lid and observe whether petrol issues from the jet (see Fig. 24). If it does not, then the passage to the jet is blocked by dirt. In order to free this, start the engine and open the




FIG. 25. CLEARING AN OBSTRUCTED JET

throttle, then block the air inlet by placing the hand over it (Fig. 25), keeping the throttle open until the engine starts to race.

Carburettor Adjustment. Make adjustments when the engine has reached its normal running temperature. Unscrew the slow running control on the dash until it is clear of the accelerator control. Screw the jet adjusting nut upwards as far as it will go and disconnect the mixture control wire from the end of the brass lever actuating the jet. Pull this jet actuating lever upwards towards the body of the carburettor as far as it will go, then slowly move it downwards away from the carburettor until the engine idles evenly, firing on all four cylinders. The jet adjusting nut should now be unscrewed until its head just comes into contact with the jet head. This will be the normal slow running position when the engine is hot, and as the jet needle is of the

correct size the performance of the carburettor on the road should be satisfactory. The mixture control wire can now be reconnected to the jet lever and the final slow running adjustment carried out with the spring loaded throttle stop screw.

S.U. PETROLIFT

One of the greatest dangers in the case of serious accidents, such as the overturning of a car, is the presence of a large quantity of petrol inside the body. This has been overcome by fitting the petrol tank outside the body at the rear of the chassis, and it is in this position that we find the petrol tank. It will be realized that the petrol in the tank is below the level of carburettor and, therefore, a means must be found to raise the petrol from that level and to gravity feed the carburettor. This is done by means of the S.U. Petrolift, a very simple and ingenious device about which we will give a short description and a few hints on maintenance.




FIG. 26. WORKING PRINCIPLES OF S.U. PETROLIFT

I may safely assume that the majority of my readers will understand the working of a simple pump—perhaps I may call it the village pump—with which water is raised from a well.

We know that this type of pump consists of a cylinder *G* (Fig. 26), into which is fitted a piston *F*, and that the piston is operated by the hinged lever *E*. At the base of the cylinder is fitted a flap valve *B*. The piston which has a hole bored in it is also fitted with a valve *A*. On the upward stroke of the piston the valve in the piston head is closed and water is drawn into the cylinder through the intake *C*, the incoming water causing the valve to rise. On the downward stroke of the piston, the inlet valve is automatically closed by the tendency of the water to run back through the intake. At the same time the descending piston compressed the water, and this is forced into the space above the piston via the valve *A*. As the piston again rises the valve *A* closes, and the water is discharged by the outlet *D*.

The principle of the Petrolift is fundamentally the same, except that we do not have to operate the pump by hand. This is done electrically. In the top of the body of the Petrolift is a cork float. Petrol in this chamber causes the float to rise and fall,

and when the petrol reaches a predetermined low level an electrical contact is made which causes a solenoid coil to be charged with electricity from the starter battery. This causes the piston to rise and draw petrol from the rear tank, which rises into the upper chamber from whence it is gravity fed to the carburettor. This function is entirely automatic, and it will be readily understood that a constant flow is maintained, no matter how heavy or light the demand from the engine.

The construction of this instrument is extremely simple, and it is very unlikely that any trouble will be experienced, but a few hints it is hoped will not be out of place.

Should it cease to function, the trouble will probably be due to—

1. The pump plungers *C* or *K* (Fig. 27) sticking, due to dirt or grit getting between the pump plungers and the body. Often a blow on the pump with the fist is sufficient to get it working, when the dirt will pass right through. Should it not do so, the remedy is to remove the filter bowl *U* and foot valve *Y*, also the top cap of the pump and the cork float, when it will be possible to push the plunger *C* through the bottom, after which a clean rag can be drawn through the bore of the pump. Note, when assembling the plunger of the pump that valve *E* is on top.

If the above is found to be in order—

2. First of all remove the top cap *V* from the pump to see if the float chamber contains petrol. If it does, then the trouble is not due to the pump.

3. If the pump continues to make a pumping noise without delivering petrol, it is due to one of the following causes—

- (a) Lack of petrol in the back tank.

- (b) Air leak, which may be due to (i) a bad joint between the filter bowl *U* and the casing, in which event tightening up will generally correct. If it does not do so a new washer will have to be fitted; or (ii) a loose petrol union on the suction pipe, that is to say any point between the bottom union of the pump and the back tank. The washer between the filter bowl and its bolt *T* should also be inspected.

- (c) Foot valve *F* held up. This is a very rare source of trouble. To rectify, remove the filter bowl *U*, filter *H*, and foot valve *Y* by means of a tommy bar through one of the holes. The foot valve can then be cleaned. A second filter *X* will be found in the foot valve underneath the priming tube.

4. If the pump works very slowly without delivering petrol, it is due to—

- (a) Blocked petrol pipe or filters, in which case the filters or pipe must be cleaned out.

- (b) Batteries run down, in which case fill the float chamber of the pump with petrol. This will probably enable the engine




FIG. 27. SECTION THROUGH THE S.U. "PETROLIFT"

to be started up by hand, and as the dynamo comes into action it will boost up the batteries sufficiently to run the pump.

5. Should the pump not work at all, providing the plunger has not stuck the trouble will be due to a bad electrical connection. To test this, remove the terminal from the pump and flash the wire across the pump body. If there is a bright flash this is in order. If not, the trouble is due to the batteries being run down or bad connections somewhere in the system.

The electrical apparatus is to all intents and purposes absolutely foolproof. Practically the only thing that can cause this to cease to function is a broken wire. If reference is made to the diagram (Fig. 53) the connections will be clearly seen. To gain access to the electrical part of the pump it will be necessary to remove filter bowl *U*, foot valve *F*, unscrew the large hexagon nut *W* holding the inlet ring, when the casing can be drawn off and the internal parts of the electrical equipment and connections inspected. Care must be taken to see that the cork gland washer which makes a petrol-tight joint between the inlet ring and electrical equipment, is in perfect condition. A new washer is advisable if the existing one is damaged.

When the casing is removed, care must also be taken to see that the wires are not broken, and particularly that the top wire does not come across the rocking contact plate *M*. A simple test to prove that the contacts are in working order, providing the bottom plunger has not stuck, is to remove the cap *V* from the top of the pump and lift the float *R* up and down its full stroke. If listened for intently the rocker plate can be heard to click as it breaks the contact.

If, after being reassembled, the pump works but does not deliver petrol, it should be primed by pouring a small quantity of petrol into the top chamber. If petrol is not available a few squirts of thin oil down the tube of the pump after removing the float *R* and top plunger *K* will have the same effect. Note that the oil *must* be thin.

THE S.U. ELECTRIC PETROL PRESSURE PUMP FITTED TO MORRIS EIGHTS

The diaphragm type of pump is fitted, its construction being such that it will give prolonged service with the minimum attention.

The only actual maintenance attention called for is the occasional removal and cleaning of the filter. The filter is inserted into the bottom of the pump body and can easily be withdrawn by unscrewing its hexagon attachment screw. When removed

it should be thoroughly cleaned in petrol with a stiff brush; *never* use rag.

Tracing Troubles. In the event of pump trouble, first disconnect the pump union of the pipe from the pump to the carburettor and switch on the engine. If the pump functions the shortage is due either to blockage of the petrol pipe to the carburettor, or possibly to the carburettor float needle sticking up.




FIG. 28. THE S.U. ELECTRIC PETROL PUMP IN PART SECTION
SHOWING SALIENT FEATURES

If the pump will not function after this has been done, first remove the filter, which is held in position by the brass hexagon nut at the base of the pump, and see if this is clear. Then disconnect the petrol pipe leading to the tank and blow down this with a tyre pump to ensure the pipe being absolutely clear, and reconnect the petrol pipe.

Should the pump still fail to function or only works slowly, the stoppage may be due to a bad earth return. To test for this,

make definite metallic contact between the brass body of the pump and the car chassis with the length of copper wire fitted. To ensure a good earth it may be necessary to scrape off a small portion of the black enamel with which the chassis is coated. If the pump then functions normally, the copper earth wire connections should be cleaned and remade.

A bad connection in the pump itself may sometimes be traced to the nut on the terminal inside the cover not being screwed down firmly.

Should these points be found in order, but the pump still does not work, the trouble is in the pump itself and the cause will be too much tension on the diaphragm or blackened contact points, the cause of which is the tensioning of the diaphragm. The remedy is to remove the cover from the contact points and pass a piece of thin card between the points when pressed together, so as to effect the necessary cleaning.

To release the tension on the diaphragm, remove the body from the base of the pump by undoing the small screws which hold these two parts together. The diaphragm itself will then be found to be adhered to the body of the pump, from which it will have to be separated. A knife will help in this operation, care being taken to prevent the rollers which support the diaphragm and act as a bearing from falling out. The body should then be replaced on to the base, and the screws put in loosely, but before finally tightening up it is advisable to stretch the diaphragm to its highest possible position. This is effected by switching on the pump and holding the contact points together while tightening the screws well up. This will effect a permanent cure.

In cases where the pump works intermittently or does not start clicking when the ignition is switched on, it is an indication that this trouble is occurring and it should be given immediate attention to obviate final stoppage on the road.

The Filter. The filter is situated at the bottom of the pump body and is easily removed for cleaning purposes by unscrewing the hexagon plug holding it in position. It should be removed and cleaned in petrol with a stiff brush every 1000 miles.

A Noisy Pump. In the event of the pump becoming noisy it is usually an indication that an air leak is taking place on the suction side of the pump. Check the level of the petrol in the tank and see that it is not too low; also check all unions and joints, making sure that the filter union and inlet unions are quite airtight.

The connections to the pump may still be in order but the trouble continues to persist. It is probable that an air leak has developed somewhere in the petrol feed pipe between the tank and the pump. The best way to test this is to replace the feed

pipe by a short length of temporary piping, the mouth of which can be inserted in a can of petrol. If the pump then functions properly it is obvious that a leak has developed somewhere in the feed pipe.

Beating of the pump without delivering petrol suggests that some dirt has become lodged under one of the valves, in which case they should be dismantled by unscrewing the top or delivery union and lifting out the valve cage, when they can be cleaned and reassembled. If, however, the pump struggles to pump and becomes very hot, it is probable that the pipe line has become obstructed or that the filter has become clogged.

BRAKES

The adjustment and care of the brakes is one of the most important matters in the maintenance of a motor-car. Upon them depends the life of the driver and his passengers. During the first 500 miles the maximum braking power may not be available, and adjustment may have to be carried out in order to take up the natural surface wear inevitable with new brake linings.

Brake adjustments are of a very simple nature, and on models without the Lockheed system take the form of main adjustment by a wing nut situated at the end of the brake pedal pull rod. This adjustment is revealed by removing the floorboard just in front of the driver's seat. Tightening up the wing nut will cause all four brakes to be taken up simultaneously.

It is important with any system of four-wheel brakes that the pressure on all four wheels should be equal, that is to say, that when the pedal is depressed one wheel should not be braked more than another, and therefore the careful owner will, after the first 500 miles, carry out the following procedure. With the Lockheed system fitted to the "Eights," this is automatically cared for, but the system will be described later. In the meantime, with regard to other types, the following notes should be acted upon.

Obtain a number of bricks or blocks of wood of such a size that they will support the wheels clear of the ground. Each wheel in turn is then jacked up, the blocks being placed underneath the axle (thus leaving the jack free to carry on with the operation on the other wheels). When all four wheels are clear of the ground they should be turned one by one, and nuts on the corresponding brake cable should be screwed up until the shoes can just be heard rubbing on the drum when the wheel is revolving. Each nut should then be slackened back one full turn, and the brake on that wheel will be properly adjusted. This should be done to all four wheels in turn.

If when on tour (or at any other time during the life of the car) the footbrakes require adjustment, this can be easily effected

by means of the wing nut already referred to. Do not forget to take up the wing nut adjustment of the handbrake a similar amount whenever use is made of this main adjustment, or you may find your handbrake ineffective.

It is important that during the life of the car the oiling nipples on the brake countershaft should receive a proper charge of oil at intervals of 500 miles.

Should the brakes not be satisfactory at any time it is always as well to ascertain that they are operating freely inside the




FIG. 29. SHOWING THE BRAKE ADJUSTMENT ON THE CROSS-SHAFT AND THE LUBRICATION POINTS
(From "The Autocar")

brake-drum, as although every precaution has been taken in the design to exclude dirt and wet, it is still possible after continuous running in bad weather to have some trouble from this source. To ascertain if this is the cause, it is necessary to disconnect the cables at their junction to the brake camshaft levers and see if these levers can be easily applied by hand. If not, remove the brake-drums, as described in the following paragraphs, and thoroughly scrape out and oil cams and clean camshaft bearings until they work quite freely; then reassemble the brake-drum, reconnect the brake-application cables and readjust. This work should not become necessary unless the brakes have been badly neglected.

Brake Shoes. Removal of the wheel will reveal three (two on the Eights) countersunk-headed screws between the wheel studs. Withdrawal of these screws permits the brake-drum to be drawn off the wheel studs, thus exposing the brake-shoes for examination.

Should the brake linings require renewal, the brake-shoes can be removed by unhooking their return springs. This may be done by passing a length of stout string through the end of the spring, which can then be extended sufficiently to permit of its being passed out of the eye of the brake-shoe.

On the Eights, remove also the split pins and washers from the guide-pins passing through the brake shoe webs. To release the pivot pin to allow the shoes to come away, remove the nut fastening the pivot pin to the brake cover. In the case of the rear shoes the brake return spring remains in position, and the shoes are released by removing the split pins and washers from the guide pins and releasing the pivot pin, as before.

Complete sets of brake linings and the necessary rivets may be obtained from the local Morris depot, or direct from the Morris works. When replacing the brake-shoes, care must be taken to see that they are replaced in the right position. The spring eyes are not quite in the centre of the shoes, but are offset. The shoes should be replaced so that the spring eyes are on that half of the shoe which is towards the centre of the car, or the springs may foul the wheel stud bosses at the back of the hub flange. It is a good plan to mark the shoes before removal so that they may be replaced in the same position.

If faulty functioning of the brakes is due to grease from the hubs having found its way on to the brake-drums, and this is not due to over-greasing of the hubs with the gun, it is probable that the felt oil-retaining washer is faulty and requires replacement. Since this entails removal of the hub and the use of special extracting tools, the job should be handed over to the local service depot.

Brake Lubrication. The brake gear of the 1933 Minor is equipped with oilless bearings for the camshaft levers. No lubrication attention is therefore required for these.

The oil can should be applied to all brake control fork joints and equalizing adjustment screws after every 500 miles freely.

Every 500 miles the oil gun should be applied to the oil nipples on the brake countershaft bearings and given two or three strokes.

THE HYDRAULIC BRAKES

Self equalizing hydraulic brakes are fitted to Morris Eights. They have no cross shafts, operating rods, or hinged joints to rattle or need lubrication, but are actuated by a master cylinder operated from the brake pedal. Pressure on the brake pedal is conveyed to fluid contained within the master cylinder and equally distributed by special pipe lines to each individual wheel brake.

The master cylinder and supply tank are of the automatically compensating type and maintain a constant volume of fluid in the braking system. Special expanders are fitted to all the cup joints, ensuring that the system is completely sealed and leak-proof.

Automatic expansion and contraction of the fluid in the system due to temperature changes is automatically compensated for.




FIG. 30. THE COMBINED MASTER CYLINDER AND SUPPLY TANK

- | | | |
|---|-------------------------|-----------------------|
| 1. Master cylinder head | 7. Shakeproof washer | 13. Master cup |
| 2. Cylinder head gasket | 8. Valve washer | 14. Piston |
| 3. Supply tank and master cylinder barrel | 9. Valve body | 15. Secondary cup |
| 4. Filler cap | 10. Valve cup | 16. Seeger circlip |
| 5. Nut for cylinder head | 11. Return spring | 17. Boot |
| 6. Tabwasher | 12. Retainer for spring | 18. Push rod assembly |

The fluid supply tank is mounted on the master cylinder beneath the floorboard.

The supply tank is merely a simple reservoir containing a sufficient quantity of fluid to feed the braking system under all conditions.

The Wheel Cylinders. The wheel brake-shoe cylinders are open at both ends, rigidly attached to the brake dust covers, and are each equipped with two opposed pistons with cup washers and push rods for connection to the brake-shoe ends. The open mouths of these cylinders are covered with rubber boots to prevent the entry of dirt.

Depression of the brake pedal introduces fluid to the centre of the cylinder between the opposed pistons, and they are as a result forced apart, thus applying the brakes.

Since it is imperative that all air should be withdrawn from the braking system, provision is made at each wheel brake cylinder

to expel any air which may be present in the pipe line. This consists of a "bleeder valve" situated at the top of each cylinder immediately above the pipe line union.

The Pipe Line. The pipe line is of stout gauge copper tubing, specially prepared and cleaned, and should not be replaced by piping of an inferior quality. Where spring deflection and steering movement must be provided for, special patent flexible hose connections are fitted. These, though flexible, are non-expandable, and are capable of withstanding a pressure of 6000 lb. per square inch.

Adjustments and Replenishment. The brakes on all Morris cars are carefully adjusted before leaving the Works, and all Morris dealers have instructions to check the brake adjustments before




FIG. 31. WHEEL CYLINDER DETAILS

handing the car to you. The brake mechanism should therefore require but little attention for a lengthy mileage. The supply tank filler cap should, however, be removed every 1000 miles, and the level of the fluid checked. If it is found to be particularly low it is an indication that a leak has developed somewhere in the system, and it should be traced and rectified without delay. The supply tank should be about three-quarters full of fluid, and never less than half full. *Always use Lockheed brake fluid.*

No equalization adjustment is required, since the pressure applied to the shoes will always be equal. In the case of particles of foreign matter getting on to any particular lining with the effect of retardation, these can be cleaned off by the use of petrol, afterwards roughing the brake lining with a file.

Adjustment to compensate for lining wear is provided by two hexagon adjustment bolts to be found on either side of the wheel cylinder. Jack up each wheel in turn, spin the wheel and partly rotate these bolts, turning each *away* from the wheel centre until the brake shoes come just into contact with the drum, thus stopping the wheel rotation. Then slack back this adjustment until the wheel just rotates freely and without drag. The adjustment bolts operate snail-type cams bearing against the shoes.

They are frictionally held, and require no locking device; they can easily be rotated with a spanner into the desired position. To bring the shoes closer to the drums the adjustment bolts should be rotated away from the centre of the wheel, and to bring the shoes farther away from the drums they should be rotated towards the centre of the wheel, with the spanner above the nut. When these operations have been carried out on all four wheels, all brakes should be in correct adjustment.

All brake re-lining should preferably be entrusted to a competent Morris dealer, who is also a Lockheed service agent. During the first 500 miles after re-lining the maximum braking effect may not be available, and adjustments may have to be carried out, at fairly frequent intervals, by the owner in order to take up the natural surface wear inevitable with the new brake lining.

Do not interfere with the wheel brake cylinders unless they are found to be leaking, and obviously need attention, and do not operate the brake pedal while the drums are removed, or the wheel cylinder pistons may be forced out of their cylinders.

Bleeding the System. The process of bleeding is necessary only when a portion of the system has been disconnected, or when the level in the supply tank has been allowed to fall below the half mark, thus permitting air to enter the fluid circuit. It consists of removing any air which may have found its way into the system. While this is not a difficult matter, it entails the use of special equipment to obtain the best results, and is at the best not a pleasant operation. Owners are therefore advised to entrust this work to an authorized Morris Dealer, who is also a Lockheed service agent.

The Brake Fluid. The Lockheed fluid used in the Morris Eight braking system is specially prepared for the purpose and it is important that no other fluid be introduced into the system for replenishment or serious trouble will ensue. This special fluid is unaffected by high temperatures, and is immune from freezing. Oil, petrol, paraffin and similar mediums are definitely injurious to some parts of the system, and should on no account be introduced to the system or used for cleaning purposes. If it is required to clean any parts of the braking system, they should be washed either in this special brake fluid supplied or alcohol. If alcohol is used, the parts should be well dried and treated with brake fluid before being replaced.

Leakage of Brake Fluid. Excessive consumption of brake fluid is an indication of a leak somewhere in the system. A leak may be traced by applying very heavy pressure to the brake pedal with the car stationary and checking over the various connections until the point of leakage is found. *Note.*—The pistons of the

wheel or master cylinders should never be removed. Special tools are required correctly to assemble these components and there is nothing in them to give trouble.

In Conclusion. Don't use any substitute for the special brake fluid, or you will have trouble.

Don't permit grease, paint, oil or brake fluid to get into contact with the brake linings.




FIG. 32. THE HEXAGON NUTS ON EACH SIDE OF THE HANDBRAKE ARE FOR ADJUSTMENT PURPOSES

Don't use packing compounds for the joints; only straight metal-to-metal joints should be made.

Don't use paraffin or petrol for cleaning purposes. Nothing but alcohol or brake fluid should be used.

Don't re-line one wheel with a different make of lining from that used on the others. Always use genuine Morris linings.

Don't allow the supply tank to become less than half full of brake fluid.

The Hand Brake. The hand brake on the Morris Eight is centrally situated next to the gear lever and operates the shoes in the rear brake-drums by cable mechanism. Ample and simple

equalization adjustment for the cables is provided at their junction to the brake cross shaft levers below the floorboards, and care must be taken to see that both brakes are applied with equal force in order to obtain maximum braking efficiency.

Instantaneous adjustment from the driving seat whereby both




FIG. 33. THE ARRANGEMENT OF THE STEERING MECHANISM OF THE THREE-SPEED MINOR

the hand brake-shoe controls are adjusted in unison, is provided at the junction of the brake lever pull rod with the hand lever, and it takes the form of a spring-loaded self-locking wing nut.

Great care must be taken not to take up the hand brake adjustment too tightly, or a tendency may exist for the brake to come on of its own accord when additional passengers are carried.

Other than a free use of the oil can on all joints, the hand brake mechanism requires little attention.

Front Wheels. These operate on journal type ball bearings, and are protected from dirt by a dust excluder and felt washer. The bearings are filled with grease before leaving the factory

and should only require attention once every 1000 miles, when the wheel should be removed and the oil gun applied to the nipple found on the edge of the large circular washer. Once a year it is desirable to remove the wheel hub with its ball bear-




FIG. 34. LOCK STOPS BELOW STEERING GEARBOX, AND ADJUSTMENT IN DRAG LINK FOR EQUALIZING THE LOCKS OF THE FRONT WHEEL

(From "The Autocar")

ings and clean the dust excluder. This job should preferably be handed to the service depot.

THE STEERING

Worm and Wheel. Worm and wheel steering is fitted to the three-speed Minors. The method of working is easily followed by referring to Fig. 33, but in this chapter we will deal only with possible adjustments. There are two adjustments which may be necessary. Firstly, end play in the steering column; and secondly, excessive play in the steering gear, and we will deal with these points in this order.

If end play is noticed, this may be corrected by slacking back the locknut (Fig. 34) which is to be found below the steering wheel, and giving the adjusting nut a fraction of a turn; lock the nut in position again.

Should the second adjustment become necessary (excessive play in steering wheel), first of all make sure that the play does not exist in the connections between the steering gearbox and the front axle. If these joints are all tight, there may be end float




FIG. 35. THE BISHOP CAM STEERING GEAR FITTED TO THE FOUR-SPEED MINORS

on the worm wheel, which can be eliminated by the adjusting stud provided. If there is wear on the worm wheel, the cure is to turn the worm wheel 90 degrees to a new position. To do this, remove the steering arm below the gearbox, having also removed the stop plate which spans it. Rotate the steering wheel 90 degrees to the new position and replace the steering arm. *Replace the stop plate.* These should be the only adjustments necessary to the steering gearbox and column. Lubrication is dealt with in Chapter V.

Bishop Cam Steering. This type of steering (Fig. 35) is fitted

to all four-speed Minors, and to the Series models, and below are given a few hints on maintenance.

Should any stiffness be noticed that we know is not due to half-inflated tyres, the front of the car must be jacked up so that both front wheels are clear of the ground and disconnect the rear end of the draglink from the steering drop arm. This will make it easy to ascertain whether the stiffness is due to wheel mounting and steering connections or in the steering column and gearbox. End play in the steering column can be found by lifting the steering wheel in line with the column, and if you consider this excessive we recommend you to consult your local Morris agent, as the rectification of this fault has to be done inside the steering gearbox. In the case of slackness, if it is found that this is due to lost motion between the cam and the end of the rocker shaft, this can be rectified by removing one or two of the brass shims which will be found between the coverplate and the main gearbox casing. This lost motion should be tested when the gear is in the mid-position, as the gear is so made that there is no appreciable backlash when it is in this position. On reassembling, see that the drop arm is in such a position that you obtain full lock in both directions, i.e. the wheel stub axles should come in contact with the stops on the axle beam in either direction.

Another cause of heavy steering is faulty wheel tracking, and it is as well to check this occasionally. This is a fairly simple matter. The length of the track rod should be such that the forward inside edges of the wheel rims measure $\frac{1}{8}$ in. less than does the distance between the rear edges. These measurements should be taken at axle level above the ground. It should also be ascertained that the wheel rims are true. Correct setting entails the use of a wheel alinement gauge, which the owner is not likely to possess, so we recommend that this job be done by your local Morris agent.

Shock Absorbers. An important part of the satisfactory maintenance of the car which is often overlooked is the care of the shock absorbers. These are rather out of sight, therefore out of mind, but it should be realized that, in order to obtain the utmost comfort from your trips in the car, attention must be paid to these fitments.

The Minor is fitted with Armstrong shock absorbers, which are a combination of the friction band and the friction disk types, and the tension of the band is so controlled to restrain the springs on the rebound more than on the deflection. Thus, the single and double action are combined into one type. Briefly, the construction (Fig. 36) is as follows.

Two arms are pivoted together at one end. At the two ends

which connect to the chassis and axle are fitted rubber bushes. These ensure a silent bearing which will not require attention as well as allowing for any angular movement between chassis frame and axle without causing strain to the arms of the shock absorber. The arm connected to the chassis carries a brake drum, while the arm connected to the axle carries a brake band encircling this drum. This band is kept in constant contact with




FIG. 36. THE ARMSTRONG SHOCK ABSORBER CUT AWAY TO SHOW THE DISPOSITION OF ITS COMPONENTS

the surface of the drum by a tension lever, which is spring loaded.

The load to the brake band is controlled by a coil spring which applies a constant load to the brake band. In addition to this spring load is a certain amount of wrapping action taking place as the two arms separate, and the resistance to the rebound of the spring is thereby increased. The opposite takes place when the arms come together; when the spring is deflected the band unwraps itself and so allows a free movement. The arm connected to the axle is fitted with three driving pins which engage a steel pressure plate, the function of this being to force two disk-type friction clutches in contact with the end face of the brake drum, and by this means a constant frictional damping is imparted. The pressure exerted by the pressure plate is regulated by a star-shaped spring washer, the tension of which is controlled by a central nut. As I have already stated, little or

no attention will be needed to the shock absorbers, but should it be found after, say, 2,000 to 3,000 miles, that your springs seem to cause your car to bound, it is probably due to the friction linings, which are composed of woven material, having bedded down, and in doing so caused the absorber to become slack. This is easily put right by screwing up the hexagon-headed nut




FIG. 37. ADJUSTING THE SHOCK ABSORBERS
(Do not remove the spring seating instead of a washer)
(From "The Autocar")

in the centre of the star washer one complete turn (Fig. 37). Once the bedding down of the linings has taken place it should not be found necessary to make any further adjustments for, say, 10,000 miles. This figure must not be taken as a definite time for adjustment; it may be found necessary to do so more often, as it is largely dependent upon the type of road over which the car may travel. Rough going will make it necessary to adjust sooner than I have stated above.

Armstrong hydraulic shock absorbers (see Figs. 38 and 39) are

fitted to the Morris Eight and are of the double-acting type, controlling spring action on both deflection and rebound. They are self-regulating in the sense that their shock-absorbing properties are automatically and progressively regulated to meet the road conditions prevailing. For instance, on a good road the shock absorber provides a normal resistance just sufficient to damp the spring action and avoid all trace of harshness, but when bad roads




FIG. 38. THE MAIN FEATURES OF THE ARMSTRONG HYDRAULIC SHOCK ABSORBER

are encountered and the amplitude of the spring motion is thus increased, the shock absorber automatically builds up an additional resistance which effectively damps out excessive spring motion and enables the car to traverse bad ground exceptionally comfortably.

The shock absorbers are provided with an improved regulating valve which automatically compensates for differences in the viscosity of the fluid due to changes in temperature. These shock absorbers therefore give the maximum riding comfort under all conditions.

The regulating valve of this type of Armstrong shock absorber is controlled by springs. It is correctly set by the manufacturers and cannot be altered. No adjustments are therefore possible.

Under normal conditions the shock absorber should need no attention whatever, except replenishment of the casing with oil at lengthy intervals. Providing leakage does not take place

there is sufficient oil in the casing to last 10,000 miles, or approximately one year's normal mileage. It is, however, advisable to inspect the quantity of oil in the casing at least once a year and replenish the supply, if necessary, through the filler and seal plug "N," taking care to tighten it up firmly again. Ordinary oil must not be used, and it is essential only to use the special oil prepared by Armstrong Patents Ltd. for this purpose. This is obtainable




FIG. 39

This sectional view of the latest type Armstrong hydraulic shock absorber shows main features.

in quart tins either from Messrs. Armstrong Patents or from the Service Department at Cowley at 4s. 6d. per tin.

A special packing gland is provided to prevent oil leakage past the shock absorber spindle where it emerges from the casing. Any leakage taking place at this point should immediately be rectified by tightening up the gland nut with a suitable "C" spanner.

Care must, however, be taken not to overtighten the gland nut, or undue strain will be placed on the shock absorber spindle. It is only necessary to tighten up the nut sufficiently to effect an oil seal.

The working parts of the shock absorber are sealed within the casing and cannot be interfered with.

In case of trouble the defective shock absorber should be sent for servicing to Armstrong Patents Co. Ltd., Eastgate, Beverley, E. Yorks, who make a point of rapid servicing in connection with both repairs and spares.

Clutch. The clutch fitted to the Minor is extremely simple and reliable, and no trouble should be experienced with it provided the owner follows the lubricating instructions given in Chapter V. In the clutch are two friction surfaces, the first consisting of two




FIG. 40. THE COMPONENT PARTS OF THE CLUTCH SEPARATED TO SHOW THEIR CONSTRUCTION

rings of bonded asbestos fabric, one attached to the flywheel cover plate and the other attached to the pressure plate. The second surfaces comprise both sides of a single steel disk splined to the driven shaft. Six driving pins pass through the flywheel, pressure plate, and flywheel cover plate, all of which consequently revolve together. In order that the driven plate may be gripped between the two rings of asbestos fabric or driving plates, six helical springs are housed between the pressure plate and the flywheel. In simple language, the working of the clutch is as follows: You will understand by reference to Fig. 40 that the pressure plate and the flywheel cover plate are attached to the crankshaft of the engine, while the driven plate is attached to the

shaft of the gearbox. When pressure is applied to the clutch pedal it causes the pressure plate and flywheel cover plate to move away from each other; thus the driven plate has no connection with the engine, and the shaft to the gearbox to which it is attached ceases to revolve. The reverse of course takes place when the foot is taken off the clutch pedal; this causes the two driving plates to come together, and in doing so they grip the driven plate, which in turn drives the shaft to the gearbox and so on, via the back axle to the road wheels. Although the "Eight" clutch is of somewhat different construction, the principles of operation are similar.

The clutch is intended to run dry, and oil should only be given to those points which are indicated in Chapter V. Should you ever notice the clutch is slipping, it is possible that oil may be finding its way into the clutch housing. I sincerely hope that this will not happen to any of my readers' cars, as the only cure is the removal of the gearbox. I shall not attempt to describe this procedure, but would advise you to let your local Morris agent deal with the job. Just one word about slipping clutches. Do not allow the clutch to slip indefinitely, as the centre-driven disk will become excessively hot, and the heat will very quickly destroy the asbestos fabric facings. When a new car is delivered from the works all the adjustments are correct, but in the cases where such materials as asbestos fabric are used, a certain amount of bedding down takes place, and while this is taking place these adjustments are altered slightly. This may happen in the clutch. In bedding down, the fabric will allow the pressure plate to take a position nearer the withdrawal mechanism, and this will reduce the clearance between the withdrawal levers, the withdrawal race, and the lever restraining springs. If this takes place, the clutch will tend to slip and the readjustment of the clutch must be undertaken immediately if damage is to be avoided. The adjustment is carried out as follows—

Remove the rectangular plate in the top of the clutch housing; this will give access to the adjustment for the withdrawal levers. It will probably be found that there is insufficient clearance between the lever ends and the face of the withdrawal race, and the locknut on each lever should be released, and with a screw-driver the screw should be slackened back until the clearance is $\frac{3}{32}$ in. between each lever and the face of the clutch withdrawal race (see Fig. 41).

I must stress the very great importance of making this adjustment so that there is exactly the same clearance between the inner ends and the face of the clutch withdrawal race. It is of the very greatest importance. I strongly advise the use of a strip of metal $\frac{3}{32}$ in. thick to be used as a gauge for this purpose.

When this adjustment has been made we will find that there is now a clearance of .010 in. between the end of the adjusting screw on the lever and the pressure pin when the lever is in contact with the restraining spring. Should there be any difficulty in obtaining the necessary clearance when the clearances at the end of the




FIG. 41. ADJUSTING THE CLEARANCE OF THE CLUTCH TOGGLE ARMS
(From "The Autocar")

withdrawal levers are correctly set, then the withdrawal lever restraining springs should be carefully opened out, using a screwdriver for the purpose. Lastly, lock the adjusting screws by means of the lock nuts, taking care not to disturb the setting. This is easy if the screw is held with a screwdriver while the nut is being tightened. If you have carried out this work correctly there should be an appreciable amount of play in each lever when the clutch is fully released. All that remains to be done is to replace the inspection cover. This cover is intended to function as a breather, so do not attempt to straighten the lip which is to

be found at one end. You did not bend it; it is meant to be there.

On the Eight, there should always be a free movement of $\frac{1}{2}$ in. at the clutch pedal. When the clutch pedal movement approaches this figure, it is essential to make use of an adjustment provided at the base of the clutch pedal so that it has ample clearance.

The adjustment consists of a slotted quadrant lever with serrated face to which the clutch pedal arm is held by a bolt. Slackening the locking nut enables the clutch pedal to be moved into the desired position. The serrated washer between the pedal and the quadrant lever has its serrations offset so that adjustment to the extent of half a serration can be obtained by rotating this washer through half a revolution. Be certain carefully to tighten up the locking nut after an adjustment has been carried out.

The thrust bearing consists of a solid graphite block and therefore requires no lubrication.

CHAPTER V

LUBRICATION

In this chapter dealing with lubrication, I should like to stress the very great importance of keeping your car well lubricated. Unfortunately, one hears many cars on the road "groaning" for the want of attention to the many oiling points on their chassis. It is of the utmost importance to a piece of mechanism that it should be correctly lubricated, and in using the word "correctly" I mean that the choice of lubricant is equally as important as its application to the mechanism. Every Morris engine on leaving the works is filled with Morrisol "Sirrom" (Registered) Brand, and it is to be recommended that this brand of oil should be used when the car comes under the care of the owner. The following brands of oil are also suitable should any difficulty be encountered in obtaining "Morrisol": Wakefield Patent Castrol (XL summer, and winter); Mobiloil (BB summer, A winter); Motorine M; Filtrate (Med. winter. Heavy summer); Shell (Double (Med.) winter, Triple (Heavy) summer); Essoluble (30 winter, 40 summer). If any of these alternatives is used I would stress the importance of draining the sump before filling up, as it is generally considered bad practice to mix oils in the sump. *Perhaps the most important warning of all is against the use of cheap, unnamed oils which are to be found on sale at many places. Do not under any circumstances use these oils; if you do, it may mean the ruination of your engine.*

Engine Lubrication. The oil supply is carried in a pressed steel sump below the cylinder block. On the right of the block will be found the filter cap and the oil level indicator. On withdrawing the indicator rod it will be found that there are two marks at the lower end. These marks indicate the maximum and minimum levels for the oil in the sump. Oil adhering to the rod indicates the level in the sump. This level should be checked at intervals, and in no case should the oil be allowed to drop below the lower mark on the indicator. This level should be checked every 250 miles. The following is the best method of doing this—

Withdraw the rod and wipe it clean. Again insert the rod and take the reading. The reason for doing this is that surging and splashing of oil take place when the engine is running and accurate reading is not possible unless this is done.

And now let me describe the method of lubrication of the engine taking the Minor as an example. At the front of the engine, driven from an inclined shaft, is a gear-type pump. The oil to

LUBRICATION

69

this pump is filtered by a large filter situated in the sump, thus we can always be certain of clean oil circulating.

After passing through the filter the oil passes through a large diameter pipe to the pump, and from the pump it is passed the length of the crankshaft under high pressure, the crankshaft




FIG. 42. THE LUBRICATION CIRCUIT OF THE MINOR ENGINE

being drilled for this purpose. In the course of its travel the big end bearings are lubricated; mud pockets are cut in each big end bearing. The course of the oil can easily be followed by reference to the sectional illustration of the engine (Fig. 42).

It will be understood that a certain amount of oil will be splashed from the big end bearings, and this surplus oil serves to lubricate the large roller bearing at the rear end of the crankshaft.

This surplus oil also lubricates the camshaft bearings and the cylinder walls.

From the front main bearing there is an oil lead which provides a constant supply of oil to the camshaft chain and distributor drive gears. Lubrication of the small end of gudgeon pin bearing is carried out by splash from the crankshaft. In order that we may know that the oiling system of the engine is working correctly, an oil pressure gauge is fitted to the instrument board. The driver should cultivate the habit of frequently glancing at this gauge while driving. A word about the read-




FIG. 43. REMOVING OIL FILTER FROM SUMP FOR CLEANING PURPOSES

ings on this dial will be useful. It will be found on starting from cold that the gauge will show a reading of 100 lb. to the square inch. This is due to the oil being a little thick. As the engine warms up and the oil becomes more fluid, the gauge will drop back to about 60 lb. (30-60 lb. on the Series models), and as long as it remains somewhere about this pressure all is well with the pump. Should it ever occur that the gauge drops back or even fails to register, stop the engine immediately and do not under any circumstances attempt to run the engine until the cause of the trouble has been found. Practically the only cause of loss of pressure is a fractured oil pipe. This would be either the pipe from the sump to the pump, or the pipe to the oil gauge.

Neglect to clean the filter would also cause loss of pressure owing to the pump being starved. I strongly advise the cleaning of the filter at regular intervals (every 1,000 miles). To do this, unscrew the oil pipe from the union on the side of the sump when the filter itself can be unscrewed and removed (Fig. 43). Clean the filter with paraffin, using a stiff brush for the purpose. Do not use any rag owing to the danger from fluff.

You have now been given sufficient details for the efficient lubricating of the engine, but before we pass on to the other sections a word on the importance of correct lubrication of what we can rightly call the heart of the car will not be out of place. Because you do not have to fill up with oil as often as you do with petrol, do not forget this vastly important thing: you should pay as much attention to engine lubrication as anything else on the car. If you neglect oil you will certainly get a "rough" engine, over-heating, bad loss of power, and in the end "seizing up" of pistons and bearings. It is to be hoped that you will come to regard your engine with a certain amount of affection. This may sound odd to some, but constant association with engines does tend to make one regard them as something more than just a piece of mechanism which hauls you and your family or friends about the country. Correct oiling is important, so "oil correctly."

Gearbox. Let us now turn our attention to the gearbox. Here, again, it is very important that the oil level should be correctly maintained. When the car is delivered to you it has the correct amount of oil in the gearbox, and it will not be necessary to worry about this until 500 miles have been covered. It would do no harm, however, to inspect the level after the first 250 miles. Inspection of the oil level can be carried out by the unscrewing of the plug on the side of the gearbox. The removal of the floorboards will be necessary. This is simplified on the Eight by the fitting of a dipstick level indicator, which can be withdrawn merely by removing the gearbox draught excluder.

The gearbox should be completely emptied and refilled with fresh oil after the first 500 miles. To drain the gearbox unscrew the plug which is to be found at the bottom. Just a tip; if you take the car for a short run, say two or three miles before you empty, you will find that the oil will run out more freely. Refill the gearbox with Morrisol "Sirrom" (Regd.) Brand Synchro-gear oil. Other oils for this purpose are Castrol Swanshot, Mobiloil, "C.W.," Essolube Gear Oil Medium, Filtrate Synchro, Shell Spirax gear oil, Essolube Gear Oil Medium, and Motorine Amber A.

After the first 500 miles it will only be necessary to drain and refill every 1,000 miles. Inspect the oil level at intervals and top up if necessary. Do not allow the level (Fig. 44) to drop, as this will result in harsh running.

Back Axle. During the first 500 miles the oil level (Fig. 46) in the back axle should be checked at intervals. This is done by removing the plug to be found on the rear of the axle casing. A dipstick is fitted on the Series models. After the first 500 miles the oil should be drained off and the axle washed out with paraffin, the method being as follows: remove the domed cover of the axle case, wash out the axle with paraffin, using a brush for the purpose, replace the cover and refill with "Morrisol"




FIG. 44. THE GEARBOX FILLING ORIFICE AND LEVEL INDICATOR

XS-Press Oil to the level indicator. The amount of oil required will be roughly one and a half pints. After this initial 500 miles it will only be necessary to drain the axle every 1,000 miles, but the careful owner will inspect the level at intervals and top up with oil if it is found necessary.

Alternative oils are: Castrol Hi-Press, Filtrate Extreme Pressure Gear Oil, Mobiloil E.P., Shell E.P. Spirax Heavy, Essoleum Expee Compound 110.

The Clutch. As already stated, the clutch thrust bearing on the Eight consists of a solid graphite block and therefore requires no lubrication. On other models, however, it should receive regular oiling. Every 500 miles the cover plate on the clutch housing should be removed and a few drops of oil

introduced to the clutch withdrawal race, through the oil duct, which is projecting from the withdrawal race sleeve to each of the six felt washers, and to the withdrawal fork bearings through the oil holes provided. Also to the splines of the clutch shaft. No difficulty should be encountered. Should it be found that the oiling holes are in a wrong position, half a turn of the engine will soon bring them to the correct position.

The Dynamo. A few drops of Wakefield "Oilit" should be




FIG. 45. REAR AXLE FILLING ORIFICE AND LEVEL INDICATOR

introduced to the oilers found at either end of the dynamo every 1,000 miles. Do not overoil—two drops *only*.

Ignition Distributor. A screw-down greaser will be found on the distributor on some models, and this should be given two complete turns every 500 miles. When empty replenish with good quality grease.

On the Eight, add two drops of thin oil to the oiler every 1,000 miles. Every 3,000 miles withdraw the rotating arm from the top of the distributor spindle and add a few drops of thin machine oil. Do *not* remove the screw which is exposed. Take care to refit the arm correctly and push it right home. Every 3,000 miles the cam should be given the slightest smear of vaseline, and every 5,000 miles a single drop of thin oil should be added to the contact-breaker pivot.

Steering Gear. Worm and wheel steering is fitted to the three-speed model and the oiling of this is as follows: with the oil gun attached to the lower Enots lubricator on the steering box the




FIG. 46. MINOR CHASSIS LUBRICATION CHART




FIG. 47. EIGHT CHASSIS LUBRICATION CHART



Bodywork. It is not generally realized by owners that some lubrication to the bodywork of a car is necessary. Here, again, we have a large area open to the elements, and it is necessary to apply a little oil or grease at regular intervals to the following places—

- | | |
|--------------------|--|
| Door locks and pin | . A little thin grease |
| Door hinges | . Wakefield "Oilit" |
| Seat slide runners | . Thin grease lightly applied |
| Sliding roof | . A few drops of thin oil to the felt pads on the end of the runners which slide in the side channels of the roof. |

GENERAL SUMMARY

A general summary follows, giving each job under a mileage heading. This will save hunting through the chapter in order to find out when a job should be done.

Every 250 miles. Inspect oil level in crankcase of engine. Inspect gearbox and back axle. Top up to correct level if necessary.

Every 500 miles. Oil clutch withdrawal race sleeve and clutch. (except Eights). Shaft splines: give two turns to greaser on distributor. Oil steering gear. Oil all chassis points.

Every 1,000 miles. Drain old oil from engine and refill with fresh oil. Clean oil filter. Drain gearbox and back axle and refill with fresh oil. Add few drops of Oilit to Dynamo and Distributor. Examine level in Lockheed brake supply tank and replenish with Lockheed Orange fluid if necessary.

Every 1,500 miles. Remove all wheels, rub over with grease, oil wheel studs and give two strokes with oil gun to nipple on end of axles. A few drops of oil ("Oilit") to dynamo bearings.

Every 3,000 miles. Add Oilit to Distributor spindle, and smear distributor cam with vaseline.

Every 5,000 miles. Add Oilit to contact-breaker points.

A word about filling and using the oil gun may save frayed tempers. Unscrew the large cap at the end of the container and by pulling on chain you will remove the automatic feed plunger to which this chain is attached. Fill the gun and replace the plunger and end cap. At the other end of the gun will be found an extension piece with a strong recoil spring surrounding it. This extension forms a type of high-pressure pump, and in it will be found a recess with a hole in the centre. This recess is applied to the projection formed by the nipple, and by pushing the whole pump towards the nipple it will be found that oil will be forced under high pressure into the nipple.

As soon as the pressure is released the extension is again forced out by the return spring, and the vacuum created causes the extension to be ready for delivering the next charge. Always remember to replace the cap on the extension in order that the gun will not leak when not in use.

CHAPTER VI

THE ELECTRICAL EQUIPMENT
LIGHTING AND STARTING

THE electrical equipment consists of a dynamo which is driven by the engine, the starter motor, the battery, and lamps and the necessary wiring. On the later models trafficators are fitted. The function of the dynamo is to supply the current for the operation of these fittings; it also supplies current for the operation of the ignition system which is described on page 90. The output from the dynamo is controlled by what is known as the third brush method. This method is used to regulate the output of the dynamo at high speeds and to keep it steady irrespective of the speed at which the dynamo is running. The dynamo speed of course must vary because it is driven by the engine. The dynamo is arranged to give alternative outputs. For instance, when running in daylight half charge can be used. This rate is only to be used in the summer when the lights are in little demand. The full charge must be used in the winter when the lights are in much greater demand. This arrangement allows you to keep your battery in good condition always. Between the dynamo and the battery is the cut-out. This is in effect an automatic switch which acts as a valve in the dynamo charging circuit, allowing a flow of current from the dynamo to the battery only. It completes the charging circuit when the dynamo is running fast enough to generate a voltage sufficiently high to charge the battery and disconnects it again when the speed is low. I wish it to be definitely known that the cut-out serves no other purpose than that of preventing current from flowing from the battery through the dynamo windings when the car is running slowly or when it is stationary. It does not prevent overcharging of the battery, as many people think.

Let us now run over the circuit in order that we may see what takes place when the equipment is in use. When we switch on we allow current to flow to the coil for the purpose of ignition. Then we depress the starter switch, and this allows current to flow and operate the starter motor. When the engine is running it is of course driving the dynamo, but no charging of the battery takes place until the cut-out operates. When the engine speed is increased the cut-out will operate and allow current to pass to the battery. You can observe the cut-out coming into operation by watching the ammeter on the

dash-board. You will notice that as the speed of the engine is increased the needle will flicker over to the charge side, the flicker indicating that the cut-out has operated. As the speed of the engine is further increased the needle will rise until it reaches maximum charging rate and will remain nearly constant, irrespective of the car speed, owing to the third brush regulating system. When the car is in use at night with lights on, current flows from the battery to the lamps. If the lamps are on when




FIG. 49. DYNAMO WITH COVER REMOVED

- | | |
|--------------------------|-----------------------|
| A = Commutator | E = Field fuse |
| B = Screw securing brush | F = Spare fuse |
| C = Brushes | G = Positive terminal |
| D = Brush tension spring | H = Field terminal |

the car is stationary and engine not running, all current for lighting has to come from the battery and the amount will be shown on the discharge side of the ammeter. When you are running with lights on, the ammeter will show the difference of the amount of current being discharged by the battery, and the current passing to the battery from the dynamo, e.g. the charging rate is 8 amps., while the lights are taking 3 amps. The ammeter will show 5 amps. on the charge side. When you stop the car the cut-out will operate and a discharge of 3 amps. will be shown.

Now let us deal with the maintenance of the equipment. Firstly, the dynamo which is situated on the platform at the front end of the engine. This really requires very little attention, but periodical inspection is recommended.

Brushes. To gain access to the brushes (Figs. 49 and 49A) slacken the single screw from the metal cover; this will allow the cover to be taken away. Be careful not to lose the nut as the cover is liable




FIG. 49A. REMOVING THE BRUSHES (SERIES MODELS)

to fly open when the screw is released. Test the action of the brush holders and see that they have sufficient spring tension to hold the brushes firmly pressed against the commutator when the dynamo is running. They should also be free to move on their pivots. This is about all that can be done to the brushes by the owner-driver. After long use the brushes will become so worn that new ones will be necessary, but I do not advise you to do this job yourself but rather go to a Lucas service depot, in order that the necessary job of bedding down can be done properly.

The Commutator. The commutator upon which the brushes press will need cleaning at intervals in order to keep it free from oil and dust from the brushes. If the car is in regular use this should be done about once a month. Do not neglect this job as dirt will cause sparking at the brushes which will have the effect of shortening the life of the dynamo. It is a very easy matter to clean; all that is needed is a clean duster and a piece of suitably shaped wood. Stretch the duster over the end of the wood and hold it against the commutator, slowly revolving

the armature as you do so. Make sure that the segments or slots in the commutator are quite clean and free from dust. If they are not, clean them out by using part of an old hacksaw blade. Do not exert too much pressure when doing this for fear of damaging the material in the segments.

Field Fuse. This needs little explanation, as I believe that most owners will know that fuses are really a form of safety




FIG. 49B. CUT-OUT AND FUSE (MINOR MODELS)

- | | |
|-------------------|--|
| A = Cut-out cover | D = Clip for securing fuse cover |
| B = Fuse cover | E = Fuse in auxiliary accessories circuits |
| C = Spare fuse | |

valve which will break the circuit should any fault occur and so save considerable damage to the equipment. A fuse in the dynamo field circuit will be found in the rectangular unit on the dynamo. On the Series, the fuse is housed in the cut-out and fusebox on the engine side of the dash. The fuse is of the cartridge type fitted into two clips. If it is found that the dynamo is failing to charge (this is indicated by the ammeter showing a discharge during daytime running) the fuse should be inspected. If it is found that the fuse has blown it should be replaced with the spare fuse supplied (see Figs. 49B and 50). Should it blow again after the engine has been started I advise you to take the car to a service station, as the trouble may be serious. Replacement fuses are of the 8 amp. type, and no attempt should be made to use any other type or value.

Lubrication. The only lubrication necessary is a few drops of

oil every 1,000 miles introduced in the lubricator at either end of the dynamo. The bearings are packed with grease on leaving the works. They will need repacking after 5,000 miles have been covered, and I advise you to have this done at a service station, as the treatment is of a special nature.

STARTER MOTOR

The armature spindle of the starter motor is fitted with a pinion which engages with a geared ring integral with the flywheel of the engine. The pinion is absolutely automatic in action.




FIG. 50. CUT-OUT AND FUSE BOX (SERIES MODELS)

When the starter switch is depressed the pinion engages with the flywheel. When the engine starts the pinion returns to its original position. Should it be found that the pinion does not engage, examine the screwed sleeve on the shaft to make sure that it is free from dirt. If necessary, clean with paraffin and give a few drops of thin oil. Very rarely the starter pinion becomes jammed in mesh. Should this happen it is easily freed by removing the metal cap at the end of the starter motor and turning the squared end of the shaft with a spanner. The commutator and brushes should be kept clean in the same manner as the dynamo. It will amply repay you to exercise some thought in the use of your starter. Do not try starting your engine on a cold morning without first giving a few turns with the starting handle with the carburettor flooded; this will free the pistons in the cylinders and thus make it easier for the starter to turn the engine. The engine should be switched off

when turning the engine by hand. Do not forget to switch on again when you use the starter.

A few things to observe when starting the engine—

1. Always retard the ignition where manual advance is fitted. This minimizes the possibility of back-firing.
2. Operate the starter switch firmly without hesitation.
3. Never operate the starter when the engine is running. If the engine does not fire at once, allow it to come to rest before operating the switch again.

Maintenance of Coil Ignition System, and Lighting System. In the following paragraphs I give all the information which I consider necessary for the satisfactory maintenance of the ignition system, together with a brief explanation of how it works.

Current from the battery is passed to the coil which consists of an iron core around which are wound the primary or low tension and the secondary or high tension windings, and it is the function of the coil to convert the battery voltage of 6 volts to a voltage somewhere in the region of 6,000 volts which is necessary to form a spark across the plug points. When you switch on the ignition, current flows from the battery through the primary winding. This current is interrupted by means of the contact breaker, which causes a high voltage to be induced in the secondary winding. The distributor moulding is provided on the inside with metal inserts, which are in contact with the high tension cables which connect to the sparking plugs. The centre terminal of the distributor moulding is connected on the outside to the high tension terminal on the coil and on the inside it is connected by means of a carbon brush contact to the rotating distributor arm. This arm is provided at its outer tip with a metal electrode, which, when the arm rotates, passes very close to the metal inserts. So the cycle of events is as follows—

When the starter shaft is depressed the distributor shaft rotates, causing the contact breaker points to make and break alternately. This causes, every time the points open, a high secondary voltage, which will be passed from the coil to the distributor arm. From here it jumps the gap to one of the metal inserts in the distributor moulding, which in turn is connected by cable to the sparking plug. Immediately after the spark occurs, the contact breaker points will close and the cycle of operations will be repeated for the spark to occur in the cylinder next in firing order. Very little attention is needed to keep the ignition system in good condition. I will run over all the points which I advise you to give a periodical inspection. I am strongly in favour of doing these jobs at fairly regular intervals, as experience has taught me that it is far better to spend time in the comfort of a garage than having to make adjustments

on the road through ignition trouble. I have found that these things generally wait for unfavourable conditions to manifest themselves.

Firstly, there is the coil. This will not need to be touched as no adjustment can be made to it. I can only advise you to keep the connection terminal clean and tight. Keep the moulded




FIG. 51. DISTRIBUTOR TYPE DJ4

- | | |
|------------------|-------------------------------|
| A = Carbon brush | F = Condenser |
| B = Electrodes | G = Rotating distributor arm |
| C = Contacts | H = Distributor arm electrode |
| D = Locking nut | J = Contact breaker pivot |
| E = Rotating cam | |

top clean and free from dirt or oil. At intervals remove the distributor moulding (Fig. 51). Examine the electrodes for any deposit, if they are at all dirty, clean them with a cloth which has been dampened with petrol. Wipe the distributor with a clean dry rag. Examine the carbon brush, and make sure that it slides freely in its holder. Clean the outside of the moulding, paying particular attention to the spaces between the terminals. Now examine the contact breaker points, and here it is very important that the contacts are kept free from any grease or oil. If they are burned or blackened they may be cleaned with very fine emery cloth, and after with a cloth moistened with petrol. Take special care to see that all particles of dirt and metal dust are wiped away. Failure to keep the contacts clean will result in misfiring.

The contact breaker gap is carefully set before leaving the

works, and a gauge is provided on the spanner dispatched with each distributor. To test the gap, slowly turn the engine over by hand until the contacts are seen to be fully opened. Now insert the gauge on the spanner in the gap; if it is correct the gauge should be a sliding fit. It is not advisable to alter the setting unless the gap varies considerably from the gauge. If




FIG. 52. DISTRIBUTOR TYPE DK4A

adjustment is necessary, proceed as follows. So far as all models except the Eight are concerned.

When the contacts are fully opened, slacken the locking nut "D" on the stationary contact screw, and rotate it by its hexagon head until the gap is set to the thickness of the gauge. After making the adjustment, care must be taken to tighten the locking nut. With the Eight slacken the two screws in the contact-breaker plate and move the plate until the gap is set to the thickness of the gauge.

Lubrication of Distributor. The main bearing of the distributor of the earlier models is lubricated from a greaser; this should be filled with a good quality grease, and should be given one turn about every 500 miles. With the Eight, the oiler should be given one or two drops of thin machine oil every 1,000 miles. The cam should be given the slightest smear of vaseline about every 3,000 miles or whenever it appears dry. The pivot of the contact

breaker should be given a single drop of oil about every 5,000 miles. This is all the lubrication necessary to the ignition system.

Before passing on to the detection and remedy of ignition faults I would advise you to examine the high tension cables from time to time in order to be sure that they are not perished or cracked. If you find the cables faulty replace them at once, using 7 mm. high tension cable for the purpose; the method of renewing is as follows—

Thread the knurled moulded nut over the cable, bare the end of the cable for about $\frac{1}{4}$ in. and thread the wire through the brass washer and bend back the strands over the side of the washer. Then screw the nut into its terminal.

Ignition Warning Lamp. This lamp is incorporated in the instrument panel. It automatically gives a red light whenever the ignition is switched on and the engine is stationary, and so reminds you to switch off. This reduces the possibility of the battery being discharged by current flowing through the coil windings. It will also be noticed that the light will remain alight when the engine is running slowly. This is because the lamp is connected across the cut-out points and will light up at speeds below the cutting-in speed of the dynamo.

Should the lamp burn out at any time replace with a 2.5 volt .2 amp. screw-cap type.

Trafficators. Every two or three months raise the trafficator arm and, by means of a brush or other suitable article, apply a drop of thin machine oil to the hinge between the arm and operating mechanism.

To replace a bulb, switch the trafficator on and then, supporting the arm, move the switch to the off position. Withdraw the screw on the underside of the arm and slide off the metal plate, when the burnt out bulb can be replaced. To replace the metal plate, slide it on in an upwards direction so that the side plates engage with the slots on the underside of the spindle bearing. Finally, secure the plate by means of its fixing screw.

THE DETECTION AND REMEDY OF IGNITION FAULTS

If a failure of ignition or misfiring occurs, unless the cause is at once apparent, the owner is strongly recommended to proceed in accordance with the table on the page 92, which should quickly enable him to locate the trouble.

Before proceeding with the examination, make sure that the trouble is not due to defects in the engine, carburettor, petrol supply, sparking plugs, etc.

Engine Will Not Fire. Switch on the ignition, turn the engine and observe the ammeter reading. The engine should

be turned by hand if it is known that the battery is in a low state of charge.

If an ammeter reading is given which rises and falls with the closing and opening of the contacts, then the low tension wiring is in order. If the reading does not fluctuate in this way, a short in the low tension wiring is indicated, or the contacts are remaining open. When no reading is given, a broken or loose connection in the low tension wiring is indicated, or the battery may be exhausted.

If an ammeter is not included in the set, the low tension wiring may be checked as follows: switch on the ignition and turn the engine by hand until the contact breaker points are closed. If the movable arm of the contact breaker is now pulled quickly aside with the fingers, thus separating the contacts, a spark should occur between them as they separate, indicating that current is flowing through the primary coil windings.

If a fault is indicated in the low tension wiring, examine the cables from switch or junction box to coil, and from coil to distributor. See that the battery terminals are tight and that the cables from the switch-box to the battery are secure. The battery may be dismissed as the cause of the trouble if the lamps will light.

Examine the high tension cables, i.e. cables from the coil to the distributor, and from the distributor to the plugs. If the rubber shows signs of deterioration or cracking, the cable should be renewed. Remove the distributor moulding and examine the contacts; if necessary, clean them as described. Turn the engine over by hand, and see that the contacts come together.

Test the coil independently of the distributor as follows: remove the cable from the centre distributor terminal, and hold it about $\frac{1}{4}$ in. from some metal part of the chassis and turn the engine. The sparking should be strong and regular if the coil is functioning correctly.

Misfiring and Bad Starting. Examine the high tension cables and the plugs. If necessary, adjust the gaps to the correct setting (about 20 thousandths of an inch). Sooty or oiled plugs may be dismantled and washed out with petrol.

The plugs and high tension cables may be tested by removing the plugs in turn and allowing them to rest on the cylinder head and observing whether a spark occurs at the points when the engine is turned by hand. It should, however, be noted that this is only a rough test, since it is possible that a spark may not take place when the plug is under compression.

Remove the distributor moulding and see that the electrodes and contacts are clean. If necessary, clean them as described on page 92. See that the contact gap setting is correct.

If, after carrying out the examination suggested, the cause of the trouble cannot be found, I advise that the equipment should be examined by the nearest service depot.

CARE OF THE LIGHTING SYSTEM

Headlamps. The headlamps employed have double filament bulbs which give a normal driving beam or an anti-dazzle light according to the position of the switch which operates them. A small pilot bulb is also fitted for use when the car is parked, thus effecting a saving in the current drawn from the battery where side lamps are not fitted. The pilot bulbs can also be used when driving along brightly-lit roads where visibility is good. I would stress the importance of having the lamps correctly adjusted and the occasional checking of this is advised. If the lamps are correctly alined the normal driving beam should be parallel with the road and with each other, in other words, straight ahead. If the lamps become out of alinement it has the effect of destroying the anti-dazzle properties. Alinement is very easy; the mountings are universal and are locked by a single nut. The important thing to remember is, when replacing bulbs use only the bulb specified by the makers. As the headlamp bulbs are carefully standardized the fitting of replacements will not necessitate refocusing. To remove the front of the headlamp, slacken the fixing screw at the bottom of the lamp and swing it aside from the slot. The front can then be withdrawn. When replacing, press the front on to the lamp body, locating the top of the rims first, then swing the screw in to the slot and lock the front into position. Should it be found necessary to remove the reflector, a cork washer will be found at the top of the reflector; turn this back, taking care not to damage it. This will expose a screw which, when removed, will allow the withdrawal of the reflector by turning it to the left. Do not attempt to clean the reflectors with anything else but a soft chamois leather, as the surfaces are protected with a colourless coating. *On no account use metal polish.*

Dashlamp. This operates by turning the knurled cover of the lamp which operates the switch. Withdraw the cover when it becomes necessary to replace the bulb. Turning the head to the right switches on the light. When replacing the cover make sure that the small stud is placed opposite the slot in the base.

Electric Horn. The horn is carefully adjusted before leaving the makers and should not be interfered with. Should it fail to function or become intermittent in action, make sure that the trouble is not due to a loose connection in the wiring, run-down battery, or a blown fuse. If an alteration of the note is noticed, this may be due to the horn becoming loose on the mounting.

Condition	Method of Detection of Possible Causes	Remedy
Engine will not fire.	Starter will not turn engine and lamps do not give good light. Battery discharged.	Start engine by hand. Battery should be recharged by running car for a long period during day time with charging switch in full charge position. Alternatively recharge from an independent electrical supply.
	Controls not set correctly for starting.	See that ignition is switched on, petrol turned on and everything is in order for starting.
	Remove lead from centre distributor terminal and hold it about $\frac{1}{4}$ in. away from some metal part of the chassis, while engine is turned over. If sparks jump gap regularly, the coil and distributor are functioning correctly.	Examine the sparking plugs, and if these are clean and the gaps correct, the trouble is due to carburettor, petrol supply, etc.
	If the coil does not spark, the trouble may be due to any of the following causes—	
	Fault in low tension wiring. Indicated by (1) No ammeter reading when engine is slowly turned and ignition switch is on, or (2) No spark occurs between the contact points when quickly separated by the fingers when the ignition switch is on.	Examine all cables in ignition circuit, and see that all connections are tight. See that battery terminals are secure.
	Dirty or pitted contact points.	Clean with fine emery cloth and afterwards with a cloth moistened with petrol.
Engine misfires.	Contact breaker points out of adjustment. Turn engine until contacts are fully opened and test gap with gauge on spanner.	Adjust gap to gauge.
	Dirty or pitted contact points.	Clean with fine emery cloth and afterwards with a cloth moistened with petrol.
	Contact breaker points out of adjustment. Turn engine until contacts are fully opened and test gap with gauge on spanner.	Adjust gap to gauge.
	Remove each sparking plug in turn, rest it on the cylinder head, and observe whether a spark occurs at the points when the engine is turned. Irregular sparking may be due to dirty plugs or defective high tension cables. If sparking is regular at all plugs the trouble is probably due to engine defects.	Clean plugs and adjust the gaps to about 20 thousandths of an inch. Replace any lead if the insulation shows signs of deterioration or cracking. Examine carburettor, petrol supply, etc.

I do not advise the dismantling of the horn itself but recommend you to seek the advice of the nearest service depot.

Wiring. Periodically, examine all the wiring of the car in order to make sure that it has not come adrift or is rubbing on parts of the chassis or body. Should any signs of chafing of wires be noticed, tape all such places with good quality black tape. Do not allow oil to stay on the wiring.

Anti-Dazzle System. The bulb is a special double filament type, either filament of which can be used at will, to give a normal driving beam or an anti-dazzle light as required. The main filament is located at the focus of the reflector in which the bulb is fitted, and is the source of the normal driving beam. The secondary filament is slightly in advance of the main filament, and is provided on its underside with a shield which cuts off all the rays which ordinarily would be reflected upward to cause dazzle. The combination of this forwardly placed filament and the shield results in a downward projection of a flood of light which is completely non-dazzling, and provides a driving light for an ample distance ahead.

The glass front fitted to lamps in which these bulbs are fitted is of special design, consisting of a series of vertical lenses of correct optical curvature, which spread the beam sideways so as to illuminate the full width of the road; it also diffuses the beam, giving an even field of illumination in the normal or dipped positions.


RUNNING INSTRUCTIONS AND MAINTENANCE

The Battery. It is of the utmost importance that the battery should receive regular attention, as upon its good condition depend the satisfactory running of the starting motor, the current for the lamps, and, when coil ignition is fitted, the running of the car.

The following are the most important maintenance hints—

1. Keep the acid level $\frac{3}{8}$ in. above the top of the plates.
 2. Add only distilled water, never tap water.
 3. Test the condition of the battery by taking readings of the specific gravity of the acid with a hydrometer.
 4. Never leave the battery in a discharged condition.
 5. Keep the terminals spanner tight, and smeared with vaseline.
- Also, with earth return sets, see that the nut securing the lead from the negative battery terminal to the chassis is tight.

Topping Up. At least once a month, remove the vent plugs in the top of the battery and examine the level of the acid solution. If necessary, add distilled water, which can be obtained at all chemists and most garages, to bring the level above the top of the plates, but well short of the bottom of the vent plugs. If



NOTE. Colours indicate coloured sleeveings on ends of leads.

FIG. 53. LIGHTING AND STARTING WIRING DIAGRAM

acid solution has been spilled, it must be replaced by a diluted sulphuric acid solution of the strength indicated on either the side or the cover of the battery. When examining the cells, naked lights must not be held near the vents, on account of the possible danger of igniting the gas coming from the plates.

Greasing Terminals. Examine the battery terminals and see that they are quite tight. Keep them smeared with vaseline to prevent corrosion. Keep the top of the battery clean and dry; take care not to spill water on it when adjusting the level of the electrolyte or taking specific gravity readings.

Testing the Condition of the Battery. It is advisable to complete the inspection by measuring the specific gravity of the acid, as this gives a very good indication of the state of charge of the battery.

An instrument known as a hydrometer is employed for this purpose, and is obtainable from Messrs. Lucas. Voltmeter readings of each cell do not provide a reliable indication of the condition of the battery unless special precautions are taken which make such a test unsuitable for the average owner, and on that account I do not recommend this test.

How to Use the Hydrometer. Before measuring the specific gravity of the acid solution by means of the hydrometer, see that the acid is at its correct level. Readings should be taken for each of the cells in turn after a run on the car, when the electrolyte is thoroughly mixed. The readings should be approximately the same. If one cell gives a reading very different from the rest it may be that the acid has been spilled or has leaked from this particular cell, or there may be a short between the plates. In this case I advise the owner to have his battery examined at a Lucas service depot to trace the cause and prevent the trouble from developing.

With batteries for which the strength of the acid recommended is 1.225, the specific gravity of the solution when the battery is fully charged will be 1.225-1.250. When half discharged, it will be about 1.200, and when fully discharged about 1.150.

For other types of batteries for which the strength of acid recommended is 1.285 or 1.320, the specific gravity figures are: 1.285-1.300 when fully charged, about 1.210 when half discharged, and about 1.150 when fully discharged. These figures are given assuming the temperature of the solution is about 60 degrees Fahrenheit. For fuller particulars regarding temperature corrections write to Messrs. Lucas of Birmingham, who will send you a copy of their "First Charge" instructions.

If the battery is found to be in a half-discharged or lower state of charge, leave the charging switch, if possible, in the full charge position for longer periods of running (see below). It




FIG. 53A. THE "EIGHT" WIRING DIAGRAM




FIG. 53B. SERIES WIRING DIAGRAM

should be remembered that the battery will be helped to regain its normal condition if its load is temporarily lessened, as for instance by using the side instead of the head lamps. If the gravity does not rise in a reasonable time, it is advisable to have the battery inspected at a Lucas service depot. On the other hand, if the battery is always found to be in a fully charged condition and the acid level gets unusually low, then decrease the charging time.

The battery must never be left in a fully discharged condition, and unless some long runs are to be taken it is advisable to have the battery charged up from an independent electrical supply.

Storage of a Battery. If the equipment is not used for several months, the battery must be given a small charge from a separate source of electrical energy about once a fortnight, in order to obviate any permanent sulphation of the plates. In no circumstances must the electrolyte be removed from the battery and the plates allowed to dry, as certain changes take place which result in loss of capacity.

Use of the Battery Charging Switch. The battery is the "reservoir" for the energy generated by the dynamo and once it is "full" there is no object in delivering further current to it. While it is always better to keep a battery overcharged rather than undercharged, it should be remembered that excessive overcharging will quickly reduce the acid level and tend to shorten the life of the battery.

In summer, when the lamps are very little used, keep the switch in the "half-charge" position; and in winter, when the lighting and starting load is heavier, keep the switch in "full-charge" position. For cars running under average conditions, this will ensure that the battery is kept in a fully-charged state.

However, in exceptional cases it may be advisable to use the switches out of season. For instance, if in winter the car is run regularly during the day with practically no night running, and the hydrometer readings are always found to be about 1.225 or 1.285 (according to the type of battery), and if the acid level gets unusually low, then it is probable that the battery is being overcharged. In these circumstances, move the charging switch to the half-charge position. On the other hand, if exceptional use is made of the lamps and starter in the summer, causing the battery to be in a low state of charge (hydrometer readings of 1.200 or under), then run with the charging switch in the full-charge position.

HOW TO LOCATE AND REMEDY LIGHTING TROUBLE

Symptoms	Probable Fault	Remedy
Lamps give insufficient illumination.	Battery discharged.	Charge battery either by a long period of daytime running or from independent electrical supply.
	Lamps out of alignment, or bulbs out of focus.	Aline lamps and focus bulbs.
	Bulbs discoloured through use, or reflectors dirty.	Fit new bulbs or clean reflectors.
Lamps light when switched on, but gradually fade out.	Battery discharged.	As above.
Brilliance varies with speed of car.	Battery discharged.	As above.
	Battery connection loose or broken.	Tighten connections, or replace faulty cables.
Lights flicker.	Loose connection.	Locate loose connection and tighten.
Failure of lights.	Fuse blown.	Examine wiring for faulty cables and remedy. Fit replacement fuse.
	Battery discharged.	As above.
	Loose or broken connection.	Locate and tighten loose connection, or re-make broken connection.

HOW TO LOCATE AND REMEDY STARTER MOTOR TROUBLE

Condition	Probable Fault	Remedy
Motor sluggish or fails to move engine.	If engine cannot be turned by hand, then fault is due to a stiff engine.	Locate and remedy cause of stiffness.
	If engine can be turned by hand, then trouble may be due to—	
	Battery discharged.	Start by hand. Charge battery either by a long period of day-time running or from independent electrical supply.
	Broken or loose connection in starter circuit.	See that connections to battery, starter, and starter switch are tight, and that cables connecting these units are in order.
	Starter commutator or brushes dirty.	Clean.
	Brushes worn, not fitted correctly or wrong type.	Replace worn brushes. See that brushes "bed" correctly.
	Starter pinion jammed in mesh with flywheel.	Rotate squared end of starter shaft with spanner.
Starter operates but does not crank engine.	Pinion of starter drive does not engage with flywheel, due to dirt on screwed sleeve.	Clean sleeve with paraffin and add a few drops of machine oil.
Starter pinion will not disengage from flywheel when engine is running.	Starter pinion jammed in mesh with flywheel.	Rotate squared end of starter shaft with spanner.

HOW TO LOCATE AND REMEDY DYNAMO TROUBLE

Symptoms	Probable Fault	Remedy
Ammeter fails to indicate charge when running with no lights in use, or gives heavy discharge with lights on.	Dynamo not charging due to: Broken or loose connection in charging circuit causing field fuse to blow. (When fitted.)	Examine charging circuit wiring. Tighten loose connection or replace broken lead. Particularly examine battery connections. Fit replacement fuse.
	Commutator greasy or dirty.	Clean with soft rag moistened in petrol.
Ammeter gives low or intermittent charge reading.	Dynamo giving low or intermittent output, due to—	
	Loose or broken connections in dynamo circuit.	Examine charging circuit wiring. Tighten loose connections or replace broken lead. Particularly examine battery connections.
	Commutator or brushes greasy.	Clean.
Ammeter gives high charge reading.	Brushes worn, not fitted correctly, or wrong type.	Replace worn brushes. See that brushes "bed" correctly.
	Dynamo giving high output due to—	
	Loose connections in dynamo charging circuit.	Examine charging circuit wiring, particularly battery connections. Tighten loose connections.
	Battery acid level low.	"Top up" cells with distilled water.
	Brushes not fitted correctly.	See that brushes "bed" correctly.
	Control brush position altered.	Have control brush adjustment re-set at nearest Lucas Service Depot.

CHAPTER VII

CARE OF TYRES

DUNLOP tyres are fitted as standard on all Minors and Eights and it is advisable to refit with the same make of tyre. Dunlop's attribute 90 per cent of premature tyre failure in some degree to inadequate inflation. It is necessary to determine the degree of inflation by the load to be carried, in relation to the size of tyre used, as a tyre must have sufficient air pressure to support the load. "Overloading" and "under-inflation" are different terms for the same thing. The fault usually lies in under-inflation, as the tyre section is chosen for the normal load of the car. The pressures recommended are given later.

The effects of under-inflation are as follows—

1. The rocking motion causes the tyres to become chafed, and will possibly result in their being cut through at the base of the side wall.

2. A severe "hingeing" action is developed on the shoulders of the tyre, causing undue flexion or bending, which in turn produces excessive internal friction, and there is a tendency for the plies of material to slide upon one another, so that adhesion between them is destroyed.

3. The edges of the tyre tread, not designed to resist continuous wear, are forced into contact with the road, thus increasing the risk of puncture.

4. The capacity of the tyre to resist other destructive influences is considerably reduced.

Do not, even for a short time, run with under-inflated tyres, for periodical wear may have destructive effects which will not disappear when the condition is remedied. It is advisable to test air pressure in the tyres at short intervals and remedy any deficiency. Tyre mileage, liability to tyre destruction, and more tyre troubles on the road will all be the sacrifice for any additional comfort secured by running with tyres at low pressure.

It is a mistake to reduce the pressure of tyres in hot weather, as lowering the pressure causes internal friction, resulting in more heating up. If the pressure is not sufficient a tyre will become too hot and internal friction is being developed. The effect of hot weather on tyres is negligible.

Specially designed gauges for testing pressure will be found more satisfactory than gauges attached to tyre pumps.

Never run on a tyre entirely deflated, even for a short distance,

as the flexible walls of the tyre, deprived of all support, are crushed flat and cut by the rim, and the material will be torn. There is also a danger of cutting the tube and tearing out the valve.

Though a tyre is hard wearing, one should avoid all risks of damaging even in slight ways. Sharp edges such as a kerb, struck by the tyre at speed or with a load may cause heavy strain on the material forming the casing of the tyre. This may only show later by a split of the fabric cover, though the tyre and tube may still be unharmed. The tube, however, will probably force its way into the crevice caused by the split and become worn, when a burst will follow, involving further damage to the weakened part of the cover. Cord tyres withstand impact better than canvas tyres, and only a very violent concussion will cause a split.

If a cut is deep enough to penetrate one or more plies of the casing material it should be attended to at once, as if left it will develop into a burst, which is a far more serious proposition. It is important, whenever one discovers a cut, to fill it with the special preparation sold for this purpose, in order to prevent water penetrating through the cut to the casing, which causes rapid deterioration of the material. Severe cuts should be placed into competent hands as these need vulcanized repairs.

The trouble of a tyre blowing off the rim is more likely to be caused by too small a pressure than one too large, for below a certain point it is insufficient to hold the tyre firmly in place, and a swerve of the car is likely to pull the tyre off the rim. The blow-out is probably due to reduction of pressure caused by a puncture, so before fitting a new tube examine the cover for the object which has caused the puncture. Bent steering tie rod, looseness in steering connections, unequal "set" of springs, broken spring leaf, or the wheel loose on its hubs, will cause irregular and rapid wear of tyre treads. Any faults of this kind have the effect of allowing the tyre to run in a direction which is not parallel with its diameter.

Harsh application of the brakes tends to lock the wheels and skid the tyres along the ground. In this way it is quite possible to grind off a portion of the tread completely, the extent of the damage depending, of course, upon the momentum of the car in relation to the power of the brakes.

Tram lines, although impossible always to avoid, are dangers sufficiently pronounced to discourage making a habit of regularly running along them. The rails often protrude above the level of the road, exhibiting a sharp edge that will quite likely cut the tyre, and cause unequal distribution of the tyre load. Points should always be avoided, as they are generally very sharp, and

will cut the tyre. The danger of skidding upon wet or greasy rails is too well known to need emphasis.

Oil and grease produce softening of the rubber which will eventually penetrate to the casing, causing a tendency to separate the material ply from ply. Accordingly, care should be exercised




FIG. 54. REMOVING WIRED-ON TYRE

to avoid over-lubrication generally, and especially of the back axle differential or part hubs. Also, tyres should be kept free from oil and grease, which should never be allowed to accumulate on garage floors. Petrol dissolves oil and grease quite easily, but should only be used very moderately, as it is also detrimental to rubber.

Damage to inner tubes chiefly arises as the result of penetration or failure of the cover, but there are one or two forms of misuse

which are peculiar to tubes and sometimes puzzling in their effects.

French Chalk Damage. As a lubricant, to prevent the tube adhering to the inner side of the cover, chalk is essential, except where covers are painted inside, as is the case with Dunlop tyres.

However, a perished and wrinkled condition of the tube is almost invariably due to an accumulation of french chalk. The best way of avoiding this damage is not to put any chalk inside the cover, but to dust the tube freely with it and shake off any surplus. Thus, a sufficient quantity has adhered to serve the purpose for which it is intended. Tubes damaged by chalk can seldom be repaired, as the chalk collects in little lumps, and by

This reinforced rubber washer inside the cap makes a perfect airtight seal when the cap is firmly screwed down by hand.

It is the small red rubber washer at this point which forms the actual air seal. It is essential that it should be in good condition.




FIG. 55. THE TYRE VALVE IN SECTION

Showing its internal construction and the slotted valve cap which, when reversed, can be used as a screwdriver to remove the interior

a purely physical action will wear away the rubber until it can be quite easily torn by the fingers.

Fitting Tyres. The fitting of tyres is quite an easy matter. The edges of the tyres enclose a slightly smaller wire ring, and to get the smaller tyre edge over the edge of the rim all that is necessary is to push the tyre edge at one place into the centre of the rim. The tyre edge at the opposite place will then fit in quite easily. When the tyre is inflated, it will be found that the edges will then fit quite comfortably in their correct place. The tyre cannot now be moved again, unless it is deflated.

To fit the tube, it must be very slightly inflated before placing it into position. First place the tyre on the edge of the rim, then with the valve through the hole in the rim the tube can be placed in the cover. The tube must be the correct way round before placing in the cover. Fit the cover at the edge opposite to the valve hole and press into position. A lever may be found useful for the last few inches, but always be careful not to damage

either the tube or cover. Do not force the wire edge of the rim, and while inflating, see that the edges of the cover are fitted evenly round the rim. It will be found a much easier job if opposite points are carefully fitted first.

Removing Tyres. Fig. 54 shows how to remove a tyre without damage. The tyre cannot blow-off because the edges are inextensible—neither can the tyre edges be lifted by levers from the rim shoulders over the rim edges. But by pushing the tyre edge down off the rim shoulder into the depressed centre of the rim at *D*, then the tyre can be easily lifted off the rim at *A*. You cannot, however, pull the tyre edge at *A* over the rim edge until the tyre edges at *B* are pushed off the rim shoulder *C* down into the well *D*, then tyre edge at *A* comes over the rim easily. This is an easy and simple operation, and requires no force.

Above all, remember the tyre edges are inextensible—force will only damage the tyre and cannot stretch the edge.

Valve Interior. The airtightness of the valve depends upon the proper functioning of its "interior" (Fig. 55). It may be tested for airtightness by rotating the wheel until the valve is at the top, and inserting its end in an egg-cupful of water. If bubbles appear, in spite of the fact that the valve interior has been well screwed down, it is evidence that its seating is faulty. It should be removed and replaced by a new interior. It is advisable always to have spare interiors handy, and these are procurable suitably packed in small containers.

The rim nut should be kept tightly screwed up on to the rim. This nut, in addition to holding the valve in position on the rim, forms a water seal, preventing the entry of water through the valve opening.

TYRE PRESSURES

Type	Tyre Size	Front	Rear
(1933 models)			
Two-seater . . .	3.5—19	22 lb. per sq. in.	27 lb. per sq.
Tourer . . .	3.5—19	22 lb. "	26 lb. "
Saloon . . .	3.5—19	22 lb. "	26 lb. "
Family Saloon . . .	4.0—19	24 lb. "	27 lb. "
Special Coupé . . .	4.0—19	24 lb. "	27 lb. "
(1934 models)			
Two-seater . . .	4.0—18	22 lb. "	24 lb. "
Tourer . . .	4.0—18	22 lb. "	26 lb. "
Saloon . . .	4.0—18	22 lb. "	26 lb. "
Family Saloon . . .	4.0—18	24 lb. "	27 lb. "
Special Coupé . . .	4.0—18	24 lb. "	27 lb. "
Eight: two-seater . . .	4.5—17	24 lb. "	24 lb. "
All other Eights . . .	4.5—17	28 lb. "	28 lb. "
Series Models . . .	4.5—17	24 lb. "	27 lb. "

CHAPTER VIII

THE O.H.V. MODELS

As the space available is extremely limited, I propose to give maintenance instruction only. For the reason just stated, the instruction will be of the briefest, but all *essential* wants will be dealt with.

Valve Rockers. These should be adjusted so that the clearance between the rocker and cam when the engine is hot is 0.003 in.




FIG. 56. ROCKER CLEARANCE

The rocker clearance should be .003 in. Should the rockers be dismantled at any time, care must be taken to see that upon replacement the thick portion of the eccentric bush lies within the area indicated by the arrow, or the oil supply to the cam will be stopped.

When the valves are ground-in, the rocker clearances must be reset, and it is advisable again to check the clearances when the car has run 50 to 100 miles after grinding, as the valves have a tendency to "bed down."

The valve rockers are mounted on the rocker-shaft by means of eccentric bronze bushes, which are normally locked to the

rockers by means of thin hexagon steel nuts. Adjustment of the rocker clearance is easily and quickly effected by holding the hexagon head of the bronze bush (found on one side of the rocker) by the thin spanner provided, and slacking off the steel lock nut on the other side. Rotation of the bronze bush in one direction or the other will enable the operator accurately to set the clearance. When the correct clearance has been obtained, the bush




FIG. 57. ARROW SHOWS ADJUSTING NUT

must be relocked to the rocker by tightening up the steel locknut. While tightening up this nut it is essential not to disturb the position of the bronze bush which has been reset, and it should be rigidly held in position, by the spanner provided, during the relocking operation.

Connecting Rods. It should be distinctly understood by the owner that the white-metalled bearings in the Morris Minor engine are of the full-ring butted type: the two halves of the white-metalled bearing completely encircle the connecting rod and make contact with each other at their joint, without leaving a gap and without the use of packing shims.

On no account whatever should these bearings be closed together, as this will immediately render the whole bearing non-standard and render the connecting rod valueless for future bearing replacement. The bearings are made on a system which ensures a sufficient degree of accuracy to make it totally unnecessary for the caps or rods to be touched by a file or scraper,




FIG. 58. THE OIL RESTRICTOR PIN

The pin is shown withdrawn from the housing in the cylinder head. (Make certain that it is kept clean.)

and, in fact, renders any hand fitting superfluous. The bearings are of a heavy type, in which the white metal is run direct on to the connecting rod and, if this white metal should run in use or become worn, the connecting rods should be replaced by new ones. Morris Motors Ltd. will not recognize any trouble consequent on interference with these bearings by owners. Any attention required to connecting rods should be entrusted to a competent Morris dealer.

It is important to note that when a connecting rod has been

removed for any purpose, it should be reassembled with the little-end clamp bolt on the opposite side of the oil filler orifice.

Fan-driving Belt. The fan belt should be kept fairly taut and adjusted from time to time by moving the fan lever so as to take up the slack. To do this, loosen the clamping screw, when the fan will be released, and can be reset by pushing the spindle up against the tension of the belt and locking it in the new position. During the cold weather it may be necessary to remove the fan to allow the engine to operate at the correct temperature.

Lubrication. The sump should occasionally be dismantled and cleaned. To do this, remove the screws attaching the oil sump to the bottom of the cylinder block and the union connecting the oil suction pipe at the front of the sump, when the sump may be withdrawn. It is advisable to remove the cover from the external filter and fill it full of oil, after the sump has been replaced, before starting the engine.

Every 500 miles the gauze cylinder should be removed from the external oil filter and thoroughly cleaned in paraffin. After cleaning, the filter should be filled with clean oil and care taken to screw the filter cover on tightly before starting the engine. On no account introduce paraffin into the filter.

The Oil Restrictor. At the junction of the oil delivery pipe to the cylinder head is the oil restrictor (Fig. 58) or metering pin, regulating the quantity of oil which is delivered to the overhead valve gear. Every 500 miles this restrictor pin should be withdrawn by passing a piece of stiff wire, hooked at its end, through the hole which can be seen in the end of the pin. The restrictor and its housing should be carefully cleaned before replacement. On no account file the pin, alter its shape, or otherwise interfere with it.

Should the oil gauge suddenly show a steady rise in pressure when the engine is hot, it is an indication that the restrictor is choked and requires immediate cleaning.

Gearbox. The oil in the gearbox should be drained every 5,000 miles by removing the plug underneath it, and refilling with fresh oil when the plug has been replaced.

To fill the gearbox, remove the oil-filler and inspection plug on the side of the gearbox. When the gearbox has been drained, approximately one pint of oil is required.

If the oil-filler orifice provided is always used, there is no possibility of overfilling; but if—as some owners prefer—the gear lever is removed and oil poured in from the top, the filler plug should be taken out, so that, if too much oil is poured in, the surplus may be free to escape. When using the filler orifice, make sure that the neck of this orifice is not choked with congealed oil, and that the oil poured in is actually getting to the

gearbox and not merely filling the spout. Use Morrisol "Sirrom" (Regd.) Brand Transmission Oil.

Rear Axle. This should be filled to the level of the top of the filler with approximately one and a half pints of oil, and this supply well kept up. Use Morrisol "Sirrom" (Regd.) Brand Transmission Oil. The rear axle should be drained every 5,000 miles and refilled with fresh oil.

Brake Gear. The intermediate brake shaft is carried in brackets riveted to the chassis frame cross member. On this shaft are mounted the levers operating the four-wheel brakes. A nipple is provided on each of the intermediate brake-shaft brackets for the purpose of introducing lubricant to the bearings, and these must not be overlooked.

Nipples are provided on the brake camshaft brackets on the brake flanges also. Care should be taken not to over-lubricate these, or oil may find its way on to the brake-drums, seriously reducing the brake efficiency. One pump stroke every 1,000 miles is adequate.

TYRE PRESSURES

Type	Tyre Size	Front	Rear
Morris Minor Tourer	27" × 4-0"	22 lb. per sq. in.	27 lb. per sq. in.
" " Saloon	27" × 4-0"	22 lb. "	27 lb. "
Morris Eight Saloon	4-0" × 19"	24 lb. "	27 lb. "
" " Sports Coupé	4-0" × 19"	24 lb. "	27 lb. "

Removing the Cylinder Head. There is no need to remove the electric horn suspended on the radiator stay. If it is swung round until it is above the radiator stay, it will not interfere with subsequent operations. The domed cover protecting the overhead valve gear may now be removed by unscrewing the two large wing nuts near its centre simultaneously.

The tension of the fan belt should now be released by slackening the fan bracket clamping bolt, and the top water connection should be released from the front face of the cylinder head block by removing the two attachment bolts, taking care not to lose the joint washer.

Now devote attention to the left-hand side of the engine and uncouple the exhaust pipe from the manifold, the mixture control rod at its junction to the brass lever on the carburettor, and finally the throttle control. Draw off the windscreen wiper tubing from the tube in the carburettor body and unscrew the petrol pipe at its junction to the carburettor float-chamber. The

induction and exhaust manifolds can then be removed by unscrewing the four retaining nuts located between each branch of the manifolds.

At the forward end of the cylinder-head block will be found an oil delivery pipe. Uncouple this by removing its centrally disposed retaining bolt. Beneath this pipe is an oil flow restrictor pin. If it is at all loose, withdraw it before it becomes lost.

Now attend to the items on the right-hand side of the engine. At the front will be seen a large diameter copper pipe—the oil return pipe. Uncouple this at its upper end by removing the two retaining nuts. There is no need to withdraw it from its studs, as these will draw straight out when the head is lifted. At the rear end of the engine will be found a similar pipe. Uncouple this at both the top and bottom attachments and remove it bodily, taking care not to lose the joint washers. Uncouple the high-tension wires from the sparking plugs.

Between the projecting portion of the cylinder-head block and the dynamo will be found a circular flexible coupling. Remove the two bolts which attach it to the dynamo drive yoke. This will permit the flexible coupling to be withdrawn with the cylinder head.

The cylinder head is held on to the cylinder block by ten nuts screwed on to the long studs passing through the cylinder head. Slacken off these nuts in rotation, half a turn at a time, until they are quite loose, then finally remove them. It is unwise to unscrew any one of these nuts completely before slackening off the remainder, as this will impose uneven stress upon the cylinder head, leading to its distortion.

The cylinder head is now ready to be lifted from the cylinder block. The breaking of the joint between the two will be facilitated by smartly tapping the sides of the head with a wooden mallet or with a hammer with a piece of wood interposed to take the blow. The joint may, however, not break freely, in which case it is permissible to insert a screwdriver or similar blunt wedge-shaped tool between the joint at the two places—one on either side of the engine—where the cylinder-head gasket has been cut away for the purpose. Do not insert the screwdriver too far. It should on no account be forced against the gasket, which would become damaged as a result. When the joint is broken, no difficulty should be experienced in lifting the head clear of the studs, providing it is withdrawn squarely. Place the head on a bench out of harm's way, and carefully lift the copper asbestos gasket straight off the cylinder-head studs, keeping it parallel with the upper face of the cylinder-head block and taking particular care that it is not bent or otherwise damaged in the process.

Decarbonizing. Everything is now in readiness for decarbonizing the piston crowns and the surrounding face of the cylinder block, and proceed as given on page 29.

To obtain access to the valve spring, it is necessary to remove the camshaft. This is easily achieved by unscrewing the four nuts holding the camshaft bearing caps in position. These should be given half a turn in rotation, in a similar manner to the cylinder-head retaining nuts, until they are eventually removed. The camshaft can then be lifted from its bearings and removed by passing it through the valve cover saddles. Removal of the camshaft enables all the valve rocker-arms to be swung clear of the valves.

A small wood block slightly thicker than the depth of the combustion spaces and an easy fit within them should now be prepared. Slip this block into the combustion space so that the valve heads are resting upon it, in order that the valve spring can be compressed with the special valve tool previously described, without forcing the valves open. Depression of the springs will expose two small conical cotters engaging in a groove in the pencil-like end of the valve stem. Removal of the cotters will release the valve spring cap from the valve stem, permitting its removal and releasing the valve spring. When the springs of both valves have been removed, the head may be raised from the bench and the wood block withdrawn, thus allowing the valves to be drawn from their guides. Repeat this operation on the remaining valves until they are all removed.

Reassembling the Valves. When you are satisfied that all trace of the grinding compound has been removed, the valves may be reassembled. Care should again be taken to see that they are in their correct ports. Reassembly of the valve is not a difficult matter with the aid of the valve tool sold by Morris agents. After inserting the valve in its guide and resting its head on the wood packing block, the valve spring and valve spring shroud may be placed in position with the valve spring cap resting on top of it. Engage the valve tool on the cap and depress the spring so as to expose very nearly the whole of the groove in the upper end of the valve stem. Insert the two conical cotters into the groove in the valve stem (small ends downwards, of course), and gradually release the spring. Make sure that the cotters are properly engaging in their grooves before dealing with the next valve. If the valve cover saddles have been removed, do not forget to replace them in position before reassembling the valves which are between the camshaft bearing brackets, or you will find that these are in the way and that you cannot replace the saddles.

Replacing the Camshaft. Swing all the valve rockers into position against their respective valves and replace the camshaft with the two marked teeth of its bevel wheel engaging on either side

of the marked tooth of the driving pinion (see Fig. 59). The camshaft bearing caps are dowelled into the bearing brackets so that there is no possibility of misalignment. Care should be exercised, however, to tighten up the camshaft bearing cap nuts evenly.




FIG. 59. THE CAMSHAFT TIMING WHEEL. MARKS CAN BE CLEARLY SEEN

Each should be given a partial turn at a time until all are perfectly tight.

Adjusting the Rockers. In the process of grinding-in the valves, a certain amount of metal is removed. This tends to reduce the clearance existing between the head of the valve and the under-surface of the rocker-arm. It is essential for the proper functioning of the engine that this clearance should not be less than 0.003 in., and it is therefore necessary to check the clearance of each valve with the feeler gauge attached to one of the special rocker-adjusting spanners. On one side of the rocker will be found a hexagon steel nut and on the other side a similar bronze nut. Engage the plain rocker adjusting spanner on the bronze nut and, holding it firmly in position, slacken the steel nut with the spanner

having the feeler gauge. Withdrawing the spanner from the steel nut, insert the feeler gauge between the valve rocker and the cam—after seeing that the peak of the cam for that particular valve is pointing directly upwards—and rotate the bronze nut until the feeler gauge can just be withdrawn easily. Now, holding




FIG. 60. ADJUSTING THE VALVE CLEARANCE

the spanner engaging the bronze nut exactly in this position, tighten up the steel locknut. The clearance should then again be checked to make sure that no movement of the setting took place while the locknut was being tightened up. When adjusting the rockers, care should be taken to see that the thick portion of the eccentric bronze bush is towards the centre of the engine (except when it is either at the top or bottom), or the oil supply to the cam will be stopped.

Replacing the Cylinder Head. When all the valve clearances have been correctly adjusted, the cylinder head is ready for replacement. It is first of all necessary thoroughly to clean the gasket and remove any carbon deposit adhering to its edges. If the gasket has been in any way damaged during the removal of the cylinder head, do not attempt to use it again, but immediately procure a new one. See that the new gasket does not burr up around the stud holes and that the cylinder bore openings are

clear of the cylinder bores themselves. The gasket can then be located over the studs in the cylinder block and gently pushed into position on to the upper face of the cylinder block. It will be found convenient to use a short length of tubing (a box spanner does quite well) over the studs to push the gasket in position. This should be done very gently, taking care to keep the gasket




FIG. 61. SEQUENCE OF TIGHTENING CYLINDER-HEAD STUD NUTS.

parallel with the cylinder head and not to force one end or one side down before the other. In the case of an old gasket, improved results will be obtained by lightly coating it on each side with gold size.

Turn the camshaft until the timing marks on the spiral bevel drive gears coincide, and rotate the engine by the starting handle until numbers one and four pistons are at the top of their stroke, with the metal electrode on the distributor rotating arm pointing towards No. 1 contact stud (No. 1 cylinder is the one nearest the radiator). This stud is easily located by tracing the high-tension lead from the sparking plug for No. 1 cylinder to its junction on the distributor cover. On removing the distributor cover, the position of the metal electrode on the end of the distributor rotating arm can be seen, and its position relative to this stud noted. That the pistons are exactly at the top of their travel can be ascertained by removing the rectangular plate on the clutch housing (just in front of the change speed lever), when a mark will be found on the face of the flywheel, bearing the numbers 1/4. This mark should be exactly in the centre of the opening in the clutch housing.

Having made sure that the pistons and camshaft are in their correct positions, the head may be lowered into position on to the cylinder block. The two holes in the flexible coupling should now be not very far from those on the drive yoke of the dynamo.

Rotate the drive yoke attached to the cylinder head until the bolt holes exactly coincide with those of the flexible ring. Replace the ten cylinder-head nuts, not forgetting the copper washers on the studs passing through the inlet ports, and tighten them up in the rotation indicated in Fig. 61, giving each a quarter of a turn at a time until all are up tight.

The flexible coupling bolts and washers should now be replaced in their correct positions, taking care to replace the distance washers in exactly the same position as they were originally. The oil pipes, exhaust and inlet manifolds, carburettor controls, petrol pipe, windscreen wiper tubing, sparking plugs, high-tension cables, and the valve cover should then be replaced. When replacing the oil pipe on the left-hand side of the head, make sure that the oil restrictor pin is in place (see page 109) and that it is clean.

Fill the radiator with water, start up the engine, and let it idle reasonably slowly until it is thoroughly warm. Then, switching off again, remove the valve cover and go over each of the cylinder-head nuts in turn, giving each a final tightening up. It will be found that now the engine is warm an extra half turn or so can be given to each nut. Do not attempt to speed up the engine until this final tightening has been effected. Start up the engine and ascertain that oil is exuding from the small oil passage drilled in each valve rocker-arm, and lubricating the cam surfaces. If oil is coming freely from these oil passages, the valve gear cover can be replaced, together with the bonnet, and the car is ready for the road.

After 250 miles the valve cover should again be removed, the cylinder-head nuts tightened up and the valve clearances checked.

The Dynamo. In order to obtain easy access to the dynamo for removal, it is necessary to take off the radiator. Drain the radiator by opening the tap in the lower water tank under the bonnet and, while the water is running away, take off the bonnet by removing the two retaining screws which attach the bracket at the rear end of the bonnet rod to the scuttle apron. When the radiator is empty, slacken off the fan belt by loosening the clamp bolt, and disconnect the top water connection by removing the two screws which attach it to the front face of the cylinder head. This will enable the top water connection, complete with fan, to be withdrawn with the radiator. Disconnect the rear clip on the lower hose pipe and loosen the hose from the water inlet pipe. Remove the two bolts fastening the radiator chassis frame, slacken the nuts at the rear end of the bonnet rod and release it from its bracket, and uncouple the wires from the electric horn. This will permit the removal of the radiator complete with fan assembly, bonnet rod, and horn.

Between the projecting portion of the cylinder head and the top of the dynamo will be found a circular flexible coupling. Remove the nuts on each of the four coupling bolts in turn, leaving the bolts in position, so that the coupling can be rotated by use of the starting handle to bring each bolt into a position where the nut may easily be reached.

Having removed all four nuts, take off the valve gear and clutch housing covers, and turn the engine by the starting handle




FIG. 62. REMOVING THE COUPLING BOLTS OF THE FLEXIBLE COUPLING

until the 1/4 timing mark on the flywheel coincides with the centre of clutchcase opening. This will bring the driving yoke on the cylinder head across the engine, and the driving yoke on the dynamo parallel with the engine centre line. The bolts themselves may now be withdrawn, care being taken not to lose the distance washers, which must be replaced in the same position. Removal of the bolts enables the flexible coupling to be withdrawn.

Detach the two cables on the distributor side of the dynamo, noting from which terminal they are removed, and disconnect the oil delivery pipe on the manifold side of the engine at its upper end, taking particular care not to lose the oil restrictor pin beneath it or its jointing washer.

Remove the two bolts securing the body of the large external oil filter to its supporting bracket. Now, unscrew the four set-screws which attach the dynamo to its platform at the front of the engine, releasing the dynamo and the filter bracket. Lift the dynamo approximately 1/4 in. and tilt it towards the near-side of the car until the driving yoke on the dynamo is just clear of that




FIG. 63. SHOWING HOW THE DYNAMO SHOULD BE REMOVED OR REPLACED

on the cylinder head. The dynamo can then be tilted forwards and easily withdrawn.

Replacement of the dynamo is effected in the reverse way, but it is necessary to make sure that the engine timing has not been disturbed while the dynamo was removed. Observation through the rectangular cover-plate in the clutch housing—just in front of the gear lever—should reveal the timing mark on the flywheel for Nos. 1 and 4 cylinders, exactly in the centre of the opening. Place the brass packing pieces which fit under the dynamo base in position on the dynamo platform, making sure that you replace the same number that you took off. If for any reason the dynamo is replaced by another, it may be necessary to readjust the mesh of the driving gears to obtain silent running

by suitable selection of the packing shims used. Turn the dynamo spindle until the timing mark on the dynamo drive gear coincides with the centre line of the dynamo and is at the rear—that is, ready for engagement with the correspondingly marked teeth of the drive gear on the crankshaft. The holes in the dynamo coupling yoke will then be parallel with the engine centre line. Tilting the dynamo towards the near-side of the car and holding the dynamo coupling yoke in this position, insert the drive gear into the opening of the dynamo platform, and swing the dynamo backwards and downwards into position. The gears can be felt to be meshing properly if the coupling is slightly oscillated as the dynamo is replaced, but do not overdo the oscillations or you may engage the wrong teeth.

See that the bolt holes in the dynamo base are coinciding with the holes in the dynamo platform, and then observe if the dynamo coupling yoke is exactly parallel with the engine centre line. If it is not, withdraw the dynamo, reset the coupling yoke, and reinsert the dynamo. No difficulty should be experienced in getting the dynamo in position with the correct teeth in mesh, as the distance between one tooth and the next is sufficient to make an appreciable difference to the position of the dynamo coupling yoke, a difference which is immediately discernible.

Having satisfied yourself that the correct gear teeth are in mesh, replace the oil-filter bracket and the screws in the dynamo base, taking particular care to tighten them up evenly, a partial turn at a time until all are quite tight.

Now make a final test. The flywheel mark $1/4$ should show exactly in the centre of the inspection cover opening with the distributor rotating arm pointing towards No. 1 cylinder. (This can easily be found by tracing the high-tension lead from No. 1 sparking plug to its junction on the distributor. Removal of the distributor cover should show the distributor arm directly beneath it.) The dynamo coupling bolt holes should be exactly fore and aft, and at right angles to the coupling yoke on the cylinder head.

If all the foregoing are correct, replace the flexible coupling and coupling bolts, taking care to replace the distance washers in exactly the same position as they were originally. Tighten up the nuts firmly and rotate the engine slowly by hand. If the distance washers are in the correct position, the flexible coupling should run absolutely true. If it does not do so, note where the error is and adjust the distance washers accordingly. Replace the valve cover, attach the dynamo cables on to their correct terminals, and reconnect the oil delivery pipe on to the cylinder head. It is an advantage to withdraw the oil restrictor pin before doing this and wash it in paraffin to make sure that it is perfectly clean.

Replace the radiator and bolt the upper water connection to

the forward face of the cylinder head, not forgetting to place the fan belt in position over the pulleys or to replace the jointing




FIG. 64. O.H.V. MINOR WIRING DIAGRAM

washer. Engage the rear end of the bonnet rod in its bracket and tighten up the nuts. You may now connect the horn wires to their terminals, connect up the bottom hose, and replace the bonnet, thus completing the reassembly.

RUNNING EXPENSES

Oil

RUNNING EXPENSES

Oil

[illegible][illegible]

FUEL AND OIL RUNNING EXPENSES

[illegible]

INDEX

ACCIDENTS, what to do, 5
Adjusting the brakes, 49
—— the tappets, 31

BAD starting, 88
 Battery, care of, 91
 — charging switch, use of, 96
 —, topping up, 91
 Bishop's cam steering, 58
 Brakes, 49
 —, adjustment of, 49
 —, linings of, 51
 —, lubrication of, 51
 — shoes, 50
 Brushes, care of, 81

- CARBURETTOR, 37
- adjustment, 42
- faults, 39
- Care of the car, 16
- of shock absorbers, 59
- of tyres, 100
- Chromium plating, care of, 17
- Cleaning pistons, 27
- Clutch slip, 65
- Coil ignition system, care of, 84
- Commutator, care of, 81
- Comprehensive insurance policy, 3
- Cycle of operations, 19
- Cylinder head, decarbonizing, 28

DASHLAMP, replacing, 89
Decarbonizing, 25
Detection and remedy of ignition
 faults, 87
Driving instruction, 14
 — licence, 1
 — off, 14
Dunlop tyres, 100

ELECTRIC horn, care of, 89
Electrical equipment, 79
Engine will not fire, what to do,
87

- FAULT finding tables, 97-99
- Field fuse, replacing, 82
- "Filling up," 13
- Fitting tyres, 103
- French chalk damage, 103
- Front wheels, care of, 59

GREASING battery terminals, 91
Grinding-in the valves, 28

HEADLAMPS, care of, 89
Hints on gear changing, 15
How the engine works, 19
Hydrometer, 93

IGNITION system, care of, 84
 ——— warning lamp, 87
 Insurance, 3

LICENCES, insurance, and law, 1
Lighting system, care of, 89
Lubrication, 68
 —, back axle, 72
 —, chassis, 77
 —, clutch, 72
 —, dynamo, 73
 —, gearbox, 71
 —, ignition distributor, 73
 —, steering gear, 73
Lucas-Graves anti-dazzle system,
91

MAINTENANCE and overhaul, 25
Misfiring, 88
Motorist and the law, 5

- OILING carburettor piston, 40
- "Otto" cycle, 21
- Overhaul and maintenance, 25
- Overhead valve models, 105

- PETROLIFT, failure of, 44
- Pistons, cleaning, 27
- "Pitted" valves, 29
- Plugs, types of, 33
- Preparing for decarbonizing, 25

126 THE BOOK OF THE MORRIS MINOR AND EIGHT

REGISTRATION of the car, 2
Renewing the driving licence, 2
Running-in new engines, 16

SHOCK absorbers, 59
—— ———, care of, 61
Springs, care of, 18
Starter motor, 83
Starting the engine, 13
Steering, end play in, 58
——, heavy, cause of, 59
Storing a battery, 96
S.U. Carburettor, 37
—— Petrolift, 43

TAPPET adjustment, 31
Testing battery, 91

Topping up battery, 91
Tyres, care of, 100
——, fitting, 103
——, removing, 104
——, valve interior of, 104

USE of battery charging switch, 96
Using hydrometer, 93


VALVES, grinding-in, 28
——, reassembling, 30

WINTER precautions, 18
Wiring diagrams, 92, 94, 95
Working principles of the S.U.
 Petrolift, 43
Worm and wheel steering, 57

When replacing plugs
remember to refit
with

LODGE

THE BEST PLUG IN THE WORLD



APPROVED FOR ALL MORRIS ENGINES
BY MORRIS MOTORS LTD.

WHOLLY British! Made by LODGE PLUGS LTD. RUGBY.

PITMAN'S MOTORISTS LIBRARY

The Book of the
MORRIS MINOR
AND THE
MORRIS EIGHT

JELLEY